

# 4PLS

Frequency Hopping Spread Spectrum



## INSTRUCTION MANUAL

1M23N28302

**Futaba**®

Digital Proportional R/C System



Thank you for purchasing a Futaba 4PLS-2.4GHz system.  
Before using your 4PLS-2.4GHz system, read this manual carefully in order to use  
your R/C set safely.

After reading this manual, store it in a safe place.

## **IN NORTH AMERICA**

Please feel free to contact the Futaba Service Center for assistance in operation, use and programming. Please be sure to regularly visit the 4PLS Frequently Asked Questions web site at <https://futabausa.com/>. This page includes extensive programming, use, set up and safety information on the 4PLS radio system and is updated regularly. Any technical updates and US manual corrections will be available on this web page. If you do not find the answers to your questions there, please see the end of our F.A.Q. area for information on contacting us via email for the most rapid and convenient response.

Don't have Internet access? Internet access is available at no charge at most public libraries, schools, and other public resources. We find internet support to be a fabulous reference for many modelers as items can be printed and saved for future reference, and can be accessed at any hour of the day, night, weekend or holiday. If you do not wish to access the internet for information, however, don't worry. Our support teams are available Monday through Friday 8-5 Central time to assist you.

### **FOR SERVICE:**

FUTABA Corporation of America  
2681 Wall Triana Hwy Huntsville, AL 35824, U.S.A.  
Phone:1-256-461-9399 FAX:1-256-461-1059  
<https://futabausa.com/>  
[service@futabaUSA.com](mailto:service@futabaUSA.com)

## **OUTSIDE NORTH AMERICA**

Please contact your Futaba importer in your region of the world to assist you with any questions, problems or service needs.

Please recognize that all information in this manual, and all support availability, is based upon the systems sold in North America only. Products purchased elsewhere may vary. Always contact your region's support center for assistance.

## **Application, Export, and Modification**

1. This product may be used for models only. It is not intended for use in any application other than the control of models for hobby and recreational purposes.

## 2. Exportation precautions:

(a) When this product is exported from the country of manufacture, its use is to be approved by the laws governing the country of destination for devices that emit radio frequencies. If this product is then re-exported to other countries, it may be subject to restrictions on such export. Prior approval of the appropriate government authorities may be required. If you have purchased this product from an exporter outside your country, and not the authorized Futaba distributor in your country, please contact the seller immediately to determine if such export regulations have been met.

(b) Use of this product with other than models may be restricted by Export and Trade Control Regulations, and an application for export approval must be submitted.

3. Modification, adjustment, and replacement of parts: Futaba is not responsible for unauthorized modification, adjustment, and replacement of parts on this product. Any such changes may void the warranty.

## Battery Recycling (for U.S.A.)



The RBRC™ SEAL on the (easily removable) nickel-cadmium battery and nickel-metal-hydride battery contained in Futaba products indicates that Futaba Corporation is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States. The RBRC™ program provides a convenient alternative to placing used nickel-cadmium batteries and nickel-metal-hydride batteries into the trash or municipal waste system, which is illegal in some areas.

You may contact your local recycling center for information on where to return the spent battery. Please call 1-800-8-BATTERY for information on NiCd/NiMH battery recycling in your area. Futaba Corporation's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.

**NOTE:** Our instruction manuals encourage our customers to return spent batteries to a local recycling center in order to keep a healthy environment.

RBRC™ is a trademark of the Rechargeable Battery Recycling Corporation.

- 
- No part of this manual may be reproduced in any form without prior permission.
  - The contents of this manual are subject to change without prior notice.
  - This manual has been carefully written. Please write to Futaba if you feel that any corrections or clarifications should be made.
  - Futaba is not responsible for the use of this product.

**For Your Safety As Well As That Of Others.....8**

**Explanation Of Symbols .....8**  
**2.4GHz System Precautions .....8**  
**Receiver Mode Precautions .....8**  
**Operation Precautions.....9**  
**Ni-MH/Ni-Cd Battery Handling Precautions .....10**  
**Storage And Disposal Precautions .....11**  
**Other Precautions .....11**

**Before Using .....12**

**Features .....12**  
**Set Contents .....14**  
**TransmitterT4PLS.....15**  
    Nomenclature..... 15  
    Battery Replacement Method..... 16  
    When Using The Optional Battery..... 17  
    When Exchanging The Optional Battery ..... 17  
    Low Battery Alarm..... 18  
    Power & Display Switch..... 19  
    Display When Power Switch Is Turned On .....20  
    LCD Screen Contrast .....20  
    Power Off Forgotten Alarm..... 20  
    Digital Trim Operation.....21  
    Grip Lever Operation.....21  
    Mechanical ATL Adjustment.....22  
    Wheel & Trigger Tension Adjustment.....22  
    Trigger Slide Adjustment .....23  
**About Transmitter Antenna And Receiver.....23**  
    About The Transmitter Antenna .....23  
    Receiver Terminology.....24  
    Receiver Installation .....24

**Installation .....25**

**Receiver And Servo Connections .....25**  
**Installation Safety Precautions .....26**

**Initial Set-Up .....29**

**Preparations (Transmitter).....29**  
    Receiver Type Check (RX MODE) .....29

Receiver Type Change & How To Link .....	30
Throttle Mode Check .....	33
Trims Initial Set-Up .....	33

**Function Map .....35**

<b>Operation Of Screen .....</b>	<b>35</b>
Calling The Menu Screen .....	35
Selecting Items On The Menu Screen .....	36
Value Of Each Function And Changing The Set Value .....	36
Basic Menu Japanese Katakana Character Display .....	37
<b>Function List.....</b>	<b>38</b>

**Functions .....39**

<b>Model "MODEL" .....</b>	<b>39</b>
Model Menu Display .....	39
Model Selection "SELECT" .....	40
Model memory call	
Model Copy "COPY" .....	41
Model memory copy	
Model Reset "RESET" .....	42
Model memory reset	
<b>Model Name "MDL NAME" .....</b>	<b>43</b>
Model memory name & User name, set/modify	
<b>Servo Reverse "REVERSE" .....</b>	<b>44</b>
Servo operation reversing	
<b>Subtrim "SUBTRIM" .....</b>	<b>45</b>
Servo center position fine adjustment	
<b>End Point Adjuster "END POINT" .....</b>	<b>46</b>
End point adjustment	
<b>Fail Safe Function "FAIL SAFE" .....</b>	<b>49</b>
Fail safe, battery fail safe function	
<b>Exponential Adjustment "EXP" .....</b>	<b>51</b>
Steering operation curve / Throttle curve adjustment	
<b>Servo Speed "SPEED" .....</b>	<b>54</b>
Steering/ Throttle servo delay adjustment	
<b>Throttle Acceleration "TH ACCEL" .....</b>	<b>57</b>
Function which adjusts the movement characteristic from the throttle neutral position	
<b>A.B.S. Function "TH A.B.S" .....</b>	<b>59</b>
Pulse brake	
<b>Channel 3/4 "CH3/CH4" .....</b>	<b>63</b>
Channel 3/4 Position	
<b>Steering Dual Rate/ Throttle ATL "D/R ATL " .....</b>	<b>64</b>
Steering D/R, Throttle ATL Rate	

**For Your Safety  
As Well As  
That Of Others**

**Before  
Using**

**Installation**

**Initial  
Set-Up**

**Function  
Map**

**Functions**

**Reference**

<b>Select Switch Dial Function "SW/ DIAL"</b> .....	<b>65</b>
Selection of functions operated by dial, digital trim and switch	
<b>Brake Mixing "BRAKE MIX"</b> .....	<b>68</b>
Front and rear independent brake control for 1/5GP car, etc.	
<b>Programmable Mixing "PROG MIX"</b> .....	<b>70</b>
Programmable mixing between arbitrary channels	
<b>4WS Mixing "4WS"</b> .....	<b>72</b>
Special mixing used with Crawler and other 4WS type vehicles	
<b>Dual ESC Mixing "DUAL ESC"</b> .....	<b>74</b>
Special mixing used with Crawler and other 4WD type vehicles	
<b>Gyro Mixing "GYRO MIX"</b> .....	<b>76</b>
Can be setting the Futaba car rate gyro.	
<b>CPS Mixing "CPS MIX"</b> .....	<b>78</b>
Controls the Futaba CPS-1 channel power switch.	
<b>Throttle Mode "TH MODE"</b> .....	<b>80</b>
Throttle Servo Neutral Position "SXNT" .....	80
Throttle servo forward and brake operation proportion setting	
Idle-Up "IDLUP" .....	81
Idle up at engine start	
Neutral Brake "NTBRK" .....	82
Neutral brake function	
Throttle Off (Engine Cut) "THOFF" .....	83
Engine cut off by switch	
<b>ESC Link Function "MC LINK"</b> .....	<b>84</b>
Special function, Futaba ESC (MC940CR, MC960CR, MC950CR, MC851C, MC602C, MC402CR, etc.)	
<b>Data Transfer "MDL TRANS"</b> .....	<b>92</b>
The T4PLS model memory data to another T4PLS	
<b>Timer Function "TIMER"</b> .....	<b>94</b>
Up, Fuel down, or lap timer	
<b>Lap List "LAP LIST"</b> .....	<b>100</b>
Lap timer data check	
<b>System Functions "SYSTEM"</b> .....	<b>101</b>
Liquid crystal screen contrast adjustment	
Liquid crystal screen backlighting display mode setup	
Backlight display time setup	
Backlight brightness setup	
Battery type setting	
Buzzer sound tone adjustment	
The power off forgotten alarm setting	
Item which displays the basic menu screen in katakana characters for Japanese use	
HOME screen display mode setting	

<b>Adjuster "ADJUSTER" .....</b>	<b>105</b>
Steering wheel and throttle trigger correction	
<b>Telemetry "TELEMETRY" .....</b>	<b>107</b>
Telemetry/ Log Screen Map .....	108
Telemetry Function ON/OFF .....	109
Telemetry Sensor Setting .....	110
Log Setting, Start/ Stop .....	112
Log Data List .....	114

**Reference .....** **115**

<b>Ratings .....</b>	<b>115</b>
<b>Warning Displays .....</b>	<b>116</b>
<b>Optional Parts .....</b>	<b>118</b>
<b>When requesting repair .....</b>	<b>118</b>

**For Your Safety  
As Well As  
That Of Others**

**Before  
Using**

**Installation**

**Initial  
Set-Up**

**Function  
Map**

**Functions**

**Reference**

Use this product in a safe manner. Please observe the following safety precautions at all times.

## Explanation Of Symbols

The parts of this manual indicated by the following symbols are extremely important and must be observed.

Symbols	Explanation
 <b>Danger</b>	Indicates a procedure which could lead to a dangerous situation and may cause death or serious injury if ignored and not performed properly.
 <b>Warning</b>	Indicates procedures which may lead to dangerous situations and could cause death or serious injury as well as superficial injury and physical damage.
 <b>Caution</b>	Indicates procedures that may not cause serious injury, but could lead to physical damage.

Symbols:       : Prohibited       : Mandatory

## 2.4GHz System Precautions

### **Warning**

-  Special attention should be paid before turning on the system while other cars are running or other airplanes are flying because the 2.4GHz RC system could potentially affect them.
-  Be sure to set the Fail Safe function.

## Receiver Mode Precautions

### **Caution**

-  When using the T4PLS in the T-FHSS (HIGH) and S-FHSS (HIGH) mode, always use it under the following conditions:
  - Servos** :Futaba digital servo (including BLS Series brushless servos)
  - Receiver's battery** :Matched to the ratings of the receiver and connected digital servo (dry cell battery cannot be used).
  - Transmitter mode** :RX MODE (See p.29 for setting method.)

---

Under other conditions, the set will not operate, or the specified performance will not be displayed even if it operates. In addition, it may cause servo trouble. Futaba will not be responsible for damage, etc. caused by combination with the products of other companies.

In addition, the FSU Fail Safe Unit cannot be used because the system is different. Use the fail safe function of the transmitter.
-  When using analog servos, always switch the T4PLS servo response to the "NORM" mode.
  - Transmitter mode**:"T-FHSS(NORM)", "T-FHSS(NORM)"and FHSS mode (See p.29 for setting method.)
  - Receiver's battery** :Matched to the ratings of the receiver and connected servo (dry cell battery cannot be used).

---

The set cannot operate in the "HIGH" mode. Operation in this mode will cause trouble with the servo and other equipment.

Digital servos (including BLS Series brushless servos) can also be used in the "NORM" mode.

# Operation Precautions

## Warning

- ⊘ Do not operate outdoors on rainy days, run through puddles of water or use when visibility is limited.

---

Should any type of moisture (water or snow) enter any component of the system, erratic operation and loss of control may occur.
- ⊘ Do not operate in the following places.
  - Near other sites where other radio control activity may occur.
  - Near people or roads.
  - On any pond when passenger boats are present.
  - Near high tension power lines or communication broadcasting antennas.

---

Interference could cause loss of control. Improper installation of your Radio Control System in your model could result in serious injury.
- ⊘ Do not operate this R/C system when you are tired, not feeling well or under the influence of alcohol or drugs.

---

Your judgment is impaired and could result in a dangerous situation that may cause serious injury to yourself as well as others.
- ⊘ Do not touch the engine, motor, speed control or any part of the model that will generate heat while the model is operating or immediately after its use.

---

These parts may be very hot and can cause serious burns.
- ❗ Always perform an operating range check prior to use.

---

Problems with the radio control system as well as improper installation in a model could cause loss of control. (Simple range test method)  
Have a friend hold the model, or clamp it down or place it where the wheels or prop cannot come in contact with any object. Walk away and check to see if the servos follow the movement of the controls on the transmitter. Should you notice any abnormal operation, do not operate the model. Also check to be sure the model memory matches the model in use.
- ❗ Turning on the power switches.  
Always check the throttle trigger on the transmitter to be sure it is at the neutral position.
  1. Turn on the transmitter power switch.
  2. Turn on the receiver or speed control power switch.Turning off the power switches  
Always be sure the engine is not running or the motor is stopped.
  1. Turn off the receiver or speed control power switch.
  2. Then turn off the transmitter power switch.

---

If the power switches are turned off in the opposite order, the model may unexpectedly run out of control and cause a very dangerous situation.
- ❗ When making adjustments to the model, do so with the engine not running or the motor disconnected.

---

You may unexpectedly lose control and create a dangerous situation.
- ❗ Before running (cruising), check the fail safe function.

---

Check Method; Before starting the engine, check the fail safe function as follows:
  - 1) Turn on the transmitter and receiver power switches.
  - 2) Wait at least one minute, then turn off the transmitter power switch. (The transmitter automatically transfers the fail safe data to the receiver every minute.)
  - 3) Check if the fail safe function moves the servos to the preset position when reception fails.The fail safe function is a safety feature that minimizes set damage by moving the servos to a preset position when reception fails. However, if set to a dangerous position, it has the opposite effect. When the reverse function was used to change the operating direction of a servo, the fail safe function must be reset.  
Setting example: Throttle idle or brake position

# NiMH / NiCd / LiFe Battery Handling Precautions

(Only when NiMH/NiCd /LiFe batteries are used)

For Your Safety As Well As That Of Others

## Warning

- ⊘ Never plug the charger into an outlet of other than the indicated voltage.  
Plugging the charger into the wrong outlet could result in an explosion or fire.
- ⊘ Never insert or remove the charger while your hands are wet.  
You may get an electric shock.
- ⊘ Do not use the T4PLS transmitter's battery, as the receiver's battery.  
Since the transmitter's battery has an overload protection circuit, the output power will be shut down when the high current load is applied. This may result in runaway or fatal crash.
- ❗ Always check to be sure your batteries have been charged prior to operating the model.  
Should the battery go dead while the model is operating, loss of control will occur and create a very dangerous situation.
- ❗ To recharge the transmitter battery, use the special charger made for this purpose.  
Overcharging could cause the battery to overheat, leak or explode. This may lead to fire, burns, loss of sight and many other types of injuries.

## Caution

- ⊘ Do not use commercial AA size NiCd and NiMH batteries.  
Quick charging may cause the battery contacts to overheat and damage the battery holder.
- ⊘ Do not short circuit the battery terminals.  
A short circuit across the battery terminals may cause abnormal heating, fire and burns.
- ⊘ Do not drop the battery or expose it to strong shocks or vibrations.  
The battery may short circuit and overheat; electrolyte may leak out and cause burns or chemical damage.
- ❗ When the model is not being used, always remove or disconnect the battery.  
Leaving the battery connected could create a dangerous situation if someone accidentally turns on the receiver power switch. Loss of control could occur.
- ❗ Always keep the charger disconnected from the outlet while it is not in use.

# Storage And Disposal Precautions

## Warning

- ⊘ Do not leave the radio system or models within the reach of small children.  
A small child may accidentally operate the system. This could cause a dangerous situation and injuries. Ni-Cd batteries can be very dangerous when mishandled and cause chemical damage.
- ⊘ Do not throw NiMH/NiCd/LiFe batteries into a fire. Do not expose batteries to extreme heat. Also do not disassemble or modify a battery pack.  
Overheating and breakage will cause the electrolyte to leak from the cells and cause skin burns, loss of sight, and other injuries.

- ❗ When the system will not be used for any length of time, store the system with HiMH/Ni-Cd batteries in a discharged state. Be sure to recharge the batteries prior to the next time the system is used.

If the batteries are repeatedly recharged in a slightly discharged state, the memory effect of the Ni-MH/Ni-Cd battery may considerably reduce the capacity. A reduction in operating time will occur even when the batteries are charged for the recommended time. (After discharge to 1cell E.V.=1V)

- ❗ When the LiFe batteries will not be used for a long time, to prevent it from deteriorating we recommend that it be kept in about the half capacity state instead of fully charged. Also be careful that the battery does not enter the over-discharged state due to self-discharge.

Periodically (about every 3 months) charge the battery.

### <NiMH/NiCd Battery Electrolyte>

The electrolyte in NiCd/NiMH batteries is a strong alkali. Should you get even the smallest amount of the electrolyte in your eyes, DO NOT RUB. Wash immediately with water, and seek medical attention at once. The electrolyte can cause blindness. If electrolyte comes in contact with your skin or clothes, wash with water immediately.

## ⚠ Warning

- ⊘ Do not store your R/C system in the following places.

- Where it is extremely hot or cold.
- Where the system will be exposed to direct sunlight.
- Where the humidity is high.
- Where vibration is prevalent.
- Where dust is prevalent.
- Where the system would be exposed to steam and condensation.

Storing your R/C system under adverse conditions could cause deformation and numerous problems with operation.

- ❗ If the system will not be used for a long period of time, remove the batteries from the transmitter and model and store in a cool, dry place.

If the batteries are left in the transmitter, electrolyte may leak and damage the transmitter. This applies to the model also. Remove the batteries from it also to prevent damage.

### <NiMH/NiCd/Li-ion Battery Recycling>

A used battery is a valuable resource. Insulate the battery terminals and dispose of the battery by taking it to a battery recycling center.

## Other Precautions

### ⚠ Caution

- ⊘ Do not expose plastic parts to fuel, motor spray, waste oil or exhaust.

The fuel, motor spray, waste oil and exhaust will penetrate and damage the plastic.

- ❗ Always use only genuine Futaba transmitters, receivers, servos, ESCs (electronic speed controls), NiMH/NiCd batteries and other optional accessories.

Futaba will not be responsible for problems caused by the use of other than genuine Futaba parts. Use the parts specified in the instruction manual and catalog.

## Features

**-Telemetry system**

The T4PLS transmitter has adopted the newly developed bidirectional communication system "T-FHSS"

**-2.4GHzSS (Spread Spectrum) radio communication system**

Frequency channel setting is unnecessary: Channel shifting takes place within the 2.4GHz band automatically. This system minimizes the interference from other 2.4GHz systems.

**-Model memory for 40 models**

Model names can use up to 10 letters, numbers, and symbols, so that logical names may be used. A model memory with different setups can be created by using the model copy function.

**- Menu Selection**

The setup screens are called from menu screens. The menu screen can be selected from among 2 levels (LEVEL1/LEVEL2).

**-Brake mixing for large cars (BRAKE)**

Brake mixing of the front and rear wheels of 1/5GP and other large cars can be adjusted independently.

**-4WS mixing for crawlers and other 4WS type (4WS)**

This function can be used with crawlers and other 4WS type vehicles.

**-Dual ESCs mixing for crawlers cars (DUAL ESC)**

ESC at the front and rear are controlled independently.

**-Gyro mixing (GYRO MIX)**

The sensitivity of Futaba car rate gyros can be adjusted from the T4PLS.

**-CPS-1 mixing (CPS MIX)**

LED lighting and flashing control using our CPS-1 channel power switch can be matched to steering and throttle operation by switch only.

**-Anti-skid braking system (TH A.B.S)**

This function applies the brakes so that the tires of gasoline engine cars, etc. do not lose their grip on the road even when braking at corners.

**-Throttle acceleration (ACCEL)**

Gasoline engine cars have a time lag before the clutch and brakes become effective. The throttle acceleration function reduces this time lag.

**-Throttle speed (SPEED)**

Sudden trigger operation on a slippery road surface will only cause the tires to spin and the model to not accelerate smoothly. By setting the throttle speed function, operation can be performed smoothly and easily. It also suppresses battery consumption.

**-Steering speed (SPEED)**

When you sense that the steering servo is too fast, etc., the servo operating speed (direction that suppresses the maximum speed) can be adjusted.

**-Racing timer (TIMER)**

The lap timer can record 100 lap times and total time. The timer can also be started automatically by trigger operation. The race time and audible alarm can be set.

Re-/fueling time are indicated by an audible alarm. An up timer is also provided.

**-Digital trim**

The current trim position is displayed on the LCD screen. The operating amount of 1 step can also be adjusted.

Trim operation has no effect on the maximum travel of the steering and throttle servos.

**-Function select switch / dial function (TRIM DIAL)**

This function assigns functions to 2 switches and dials (digital trim, digital dial). The step amount and operating direction can also be adjusted. Trim positioning at each model call is unnecessary because all the dials are digital.

**-ESC-Link function (MC-LINK)**

This is a dedicated function which allows setting of the contents of the Link software which makes possible Futaba speed controller (ESC), MC950CR, MC850C, MC851C, MC602C, MC402CR, etc. variable frequency and other data changes by T4PLS.

**-Trigger position can be changed**

The position of the throttle trigger can be moved forward and backward.

**-Tension adjustment function**

The tension of the steering wheel & throttle trigger springs can be adjusted from the outside.

**-Mechanical ATL Adjustment**

Make this adjustment when you want to decrease the total travel of the brake (push) side of the throttle trigger.

**-Display switch**

Display switch allows function setup without transmitting.

## Set Contents

After opening the box, first check if the contents conform to the following. The contents depend on the set as shown below.

<b>Transmitter</b>	<b>T4PLS</b>
<b>Receiver</b>	<b>R304SB</b>
<b>Miscellaneous</b>	<p><b>Dry battery holder</b> *Installed in transmitter.</p> <p><b>Receiver switch</b></p> <p><b>Mini screwdriver</b> * It is used for R304SB.</p> <p><b>Instruction manual</b></p>

Before Using

- If any of the set contents are missing, or you have any questions, please contact your dealer.

### Caution

- ① When using the T4PLS in the T-FHSS (HIGH) and S-FHSS (HIGH) mode, always use it under the following conditions:

**Servos** :Futaba digital servo (including BLS Series brushless servos)

**Receiver's battery** :Matched to the ratings of the receiver and connected digital servo (dry cell battery cannot be used).

**Transmitter mode** :RX MODE (See p.29 for setting method.)

Under other conditions, the set will not operate, or the specified performance will not be displayed even if it operates. In addition, it may cause servo trouble. Futaba will not be responsible for damage, etc. caused by combination with the products of other companies.

In addition, the FSU Fail Safe Unit cannot be used because the system is different. Use the fail safe function of the transmitter.

- ① When using analog servos, always switch the T4PLS servo response to the "NORM" mode.  
**Transmitter mode:**"T-FHSS(NORM)", "T-FHSS(NORM)"and FHSS mode (See p.29 for setting method.)  
**Receiver's battery** :Matched to the ratings of the receiver and connected servo (dry cell battery cannot be used).

The set cannot operate in the "HIGH" mode. Operation in this mode will cause trouble with the servo and other equipment.


Digital servos (including BLS Series brushless servos) can also be used in the "NORM" mode.

- ① Always use only genuine Futaba transmitters, receivers, servos, ESCs (electronic speed controls), NiMH, NiCd, Li-ion batteries and other optional accessories.

Futaba will not be responsible for problems caused by the use of other than Futaba genuine parts. Use the parts specified in the instruction manual and catalog.

# Transmitter T4PLS

## Nomenclature



Before Using


\*The switches, dial, and trimmers in the figure are shown in the initial setting position.

## Battery Replacement Method (4 AA Size Batteries)

Load the four batteries in accordance with the polarity markings on the battery holder.

### Battery Replacement Method

- 1 Remove the battery cover from the transmitter by sliding it in the direction of the arrow in the figure.
- 2 Remove the used batteries.
- 3 Load the new AA size batteries. Pay very close attention to the polarity markings and reinsert accordingly.
- 4 Slide the battery cover back onto the case.



### Check:

Turn the power switch on the transmitter to the ON position. Check the battery voltage display on the LCD screen. If the voltage is low, check the batteries for insufficient contact in the case or incorrect battery polarity.

### Disposal of the Dry Cell Batteries:

The method to dispose of used dry cell batteries depends on the area in which you reside. Dispose of the batteries in accordance with the regulations for your area.

## ⚠ Caution

- ⊘ Never try to recharge a dry cell battery.

The transmitter may be damaged or the battery electrolyte may leak or the battery may break.

- ❗ Insert the batteries in the correct polarity.

If the polarity is incorrect, the transmitter may be damaged.

- ❗ When the transmitter is not in use, remove the batteries.

If the battery electrolyte leaks, wipe off the case and contacts.

- ⊘ Do not use commercial AA size NiCd and NiMH batteries.

Quick charging may cause the battery contacts to overheat and damage the battery holder.



## When Using The Optional Battery

When using an optional rechargeable battery, replace the battery as described below.

- Always use the optional HT5F1700B or FT2F2100B rechargeable battery.
- The type of power source used must be set by system setting (P101).
- When the transmitter will not be used for a long time, remove the battery.

### Battery Replacement Method

- 1 Refer to the previous description and remove the transmitter battery cover.
- 2 After removing the dry cell battery box from the transmitter, disconnect the connector.
- 3 Insert the connector of the new battery and load the new battery into the transmitter.
- 4 Finish by installing the battery cover.

### ⚠ Caution

❗ When closing the battery cover, be careful that the battery cover does not pinch the battery lead wires.

Shorting of the battery lead wires may lead to fire and abnormal heating and cause burns or fire disaster.

Before Using

## When Exchanging For The Optional Battery

### Charge Of A NiMH Battery

(Example: When using the HT5F1800B with the special charger)

- 1 Plug the transmitter cord of the special charger into the charging jack on the rear of the transmitter.
- 2 Plug the charger into an AC outlet.
- 3 Check that the charging LED lights.



The charging time when charging the HT5F1800B battery with the optional special charger is approximately 15 hours. However, when the battery has not been used for some time, repeat charging 2 or 3 times to activate the battery.

### When using Futaba CR-2000

The HT5F1700B/1800B is 5-cells, so, when charging the HT5F1700B battery with Futaba CR-2000 charger, you have to use the RX output side.

### Over current protection

The transmitter charging circuit is equipped with an over current protection circuit (1.0A). If the battery is charged with a quick charger for other than digital proportional R/C sets, it may not be fully charged.





## Charging A LiFe Battery

(Example: When using the FT2F1700B/2100B with the special charger)

- 1** Remove the battery cover.
- 2** Disconnect the battery from the 4PLS
- 3** Balance charging cannot be done through the transmitter, you must remove the LiFe battery to do this

Charge the optional FT2F1700B/2100B (LiFe) battery with the special charger in accordance with the instruction manual supplied.

When the battery will not be used for a long time, to prevent it from deteriorating we recommend that it be kept in about the half capacity state instead of fully charged. Also be careful that the battery does not enter the over-discharged state due to self-discharge.  
Periodically (about every 3 months) charge the battery.



### Warning

-  Never plug it into an outlet other than the indicated voltage.  
Plugging the charger into the wrong outlet could result in an explosion or fire.
-  Do not insert and remove the charger when your hands are wet.  
It may cause an electric shock.
-  Always use the special charger or a quick charger for digital proportional R/C sets to charge a digital proportional R/C set Ni-MH battery.  
Overcharging a Ni-MH battery can result in burns, fire, injuries, or loss of sight due to overheating, breakage, or electrolyte leakage.


### Caution

-  When the charger is not in use, disconnect it from the AC outlet.  
Do this to prevent accidents and to avoid overheating.

## Low Battery Alarm

If the transmitter battery voltage drops below the usable range, an audible alarm will sound and "BATTERY LOW VOLTAGE" will be displayed on the LCD screen. If the battery goes dead while running (cruising), you will lose control of the vehicle (boat). Therefore, retrieve the vehicle (boat) immediately and cease operation.

Because the low battery alarm voltage of a dry cell battery is different from that of a rechargeable battery pack (genuine Futaba option), the type of power source used must be set by system setting (P101).




### Warning

- When a low battery alarm is generated, cease operation immediately and retrieve the model.  
If the battery goes dead while in operation, you will lose control of the model.

## Power & Display Switch

The power switch and display switch of the T4PLS are integrated. In the PWR ON mode, radio waves are transmitted and in the DISP mode, model data, settings can be checked without transmitting radio waves.

In addition, some setting menus may only be displayed in the DISP mode.




Radio waves are not being transmitted

Radio waves are being transmitted

### Precautions when turning the power switch on and off.

- When the data is changed using the edit keys or trim levers, wait at least two seconds before turning off the power. If the power is turned off within two seconds after the data is changed, the new data will not be written to memory.

- If the power switch is quickly switched from the DISP mode to the PWR ON mode or vice versa, the switch error shown at the right may be generated. If this occurs, cycle the power.




## Display When Power Switch Is Turned On

Power switch turned on



Before Using



Beep confirmation sound is generated and the HOME screen shown below appears.

## LCD Screen Contrast

The LCD screen contrast can be adjusted. (For more information, see page 101.)

### Caution


Do not adjust the contrast so that the LCD is too bright or too dark.  
When the display cannot be read due to a temperature change, data cannot be set.

## Power Off Forgotten Alarm

When the steering wheel, throttle trigger, push switch, or edit button are not operated for 10 minutes (default), an alarm sounds and "NOT OPERATED FOR A LONG TIME" is displayed on the LCD screen.

When the steering wheel, throttle trigger, push switch, or edit button are operated, the alarm is reset. If the system is not to be used, turn off the power.


The function can be deactivated at the system menu (p.101).



# Digital Trim Operation

(Initial settings: DT1: Steering trim, DT2: Throttle trim,)

Operating by the lever: Push the lever to the left or right (up or down) The current position is displayed on the LCD screen.



- Each step is indicated by a tone.
- When the trim exceeds the maximum trim adjustment range, the beep will change and the servo will not move any farther.
- Trim lever adjustments have no effect on the maximum servo travel. This prevents the linkages from binding when adjustments are made.


## Trim Operation

With the center trim feature, trim adjustments have no effect on the maximum servo travel. This prevents the linkages from binding when adjustments are made.

# Grip Lever Operation

(Initial setting: DT3; Steering D/R, DT4; ATL)

Operate the dials by turning them. The current set value is displayed on the LCD screen.



- Each step is indicated by a tone.
- When the trim exceeds the maximum trim adjustment range, the tone will change pitch and the servo will not move any farther.



Before Using


## Mechanical ATL Adjustment

Make this adjustment when you want to decrease the stroke of the brake (back) side of the throttle trigger for operation feel.

### Adjustment

**1** Using a 2.5mm hex wrench, adjust the trigger brake (reverse) stroke. (The screw moves the throttle trigger stopper.)

- When the screw is turned clockwise, the stroke becomes narrower. Adjust the stroke while watching the screw.



**Mechanical ATL adjusting screw**

### Note:

Once you have changed the mechanical stroke on the brake side, be sure to adjust the scale of the throttle channel accordingly by using the "Adjuster Function" (page 105).  
 Due to this change, you also need to adjust in most cases the travel of the throttle servo by using "End point Adjuster".


## Wheel & Trigger Tension Adjustment

Make this adjustment when you want to change the wheel or trigger spring's tension.

### Adjustment

**1** Using a 1.5mm hex wrench, adjust the wheel spring tension by turning the screw inside the adjusting hole in the arrow direction.

- The spring is set to the weakest tension at the factory.
- When the adjusting screw is turned clockwise, the spring tension increases.



**Wheel tension adjusting screw**

**Trigger tension adjusting screw**

### Note:


The adjustment range is up to 7 to 8 turns from the fully tightened (strongest) position. If turned farther than this, the adjusting screw may fall out.

## Trigger Slide Adjustment

The throttle trigger position can be moved forward and backward.

### Adjustment



- 1 Using a 2.5mm hex wrench, loosen the trigger slide mounting screw by turning it slightly counterclockwise.
- 2 Using a 2.5mm hex wrench, turn the trigger slide adjusting screw, and adjust the trigger slide position within the marked range. When the adjusting screw is turned clockwise, the trigger slide moves away from the grip handle.
- 3 Retighten the mounting screw loosened at step 1 and fasten the trigger slide.



Before Using

## About Transmitter Antenna and Receiver


### About The Transmitter Antenna



### ⚠ Warning

- ❶ Adjust the antenna vertically to the ground.  
Otherwise, the operating range may become shorter.
- ⊘ Never hold only the antenna.  
Hold the grip handle. Otherwise, the antenna may be damaged.
- ⊘ The antenna position can be changed in the range as shown in figures A and B. However, please do not apply unnecessary force or shock.  
The internal cable may be damaged; thus transmitting distance decreases and it may cause malfunction.

# Receiver Terminology



## Connectors

- 4 :CH4 servo(CH4)
- 3 :CH3 servo(CH3)
- 2 :Throttle servo(CH2)
- 1 :Steering servo(CH1)
- S.BUS2:Power /S.BUS2 connector

The receiver power supply can be connected to the S-BUS2 connector or each of CH1-4.

# Receiver Installation


Install the R304SB receiver on the car as follows:

The operating range may become shorter, depending on where the receiver and the antenna are mounted.

Before Using

## ⚠ WARNING

- ⊘ Do not cut or bundle the receiver antenna wire.
- ⊘ Do not bend the coaxial cable. It causes damage.
- ❗ Install the antenna in the higher place as shown in the figure.
- ❗ Put the antenna in the antenna tube to protect it.
- ❗ Keep the antenna as far away from the motor, ESC and other noise sources as you possibly can.
- ❗ Wrap the receiver with something soft, such as foam rubber, to avoid vibration. If there is a chance of getting wet, put the receiver in a waterproof bag or balloon.



## ⚠ Caution

- ❗ Always use R304SB under the following conditions:
    - Battery :Power requirement Rated voltage 4.8~7.4V (dry cell battery cannot be used) / 3.5 to 8.4V useable  
Matched to the ratings of the receiver and connected servo.
    - RX MODE:"T-FHSS(HIGH)" or "T-FHSS(NORM)" (See p.29 for setting method.)
    - Transmitter mode-"T-FHSS(HIGH)" mode :Futaba digital servo
    - Transmitter mode-"T-FHSS(NORM)" mode :Futaba all servo
- Under other conditions, the set will not operate, or the specified performance will not be displayed even if it operates. In addition, it may cause trouble with servos and other equipment. Futaba will not be responsible for damage, etc. caused by combination with the products of other companies.

### Transmitter mode setting

Set the transmitter to the "T-FHSS(HIGH)" mode or "T-FHSS(NORM)" mode. See page 29 for a description of the setting method.


**Note:** However, digital servos (including BLS Series brushless servo) can only be used in the T-FHSS(HIGH) mode.

## Receiver and Servo Connections

Connect the receiver and servos as shown below. Connect and install the receiver and servos in accordance with "Installation Safety Precautions" on the next page.


The figure shown below is an example. The method of connecting the motor controller to the motor and battery depends on the motor controller used. Purchase the motor controller and servos separately. The receiver also depends on the set.

### Installation When An Electronic Speed Control Is Used



Installation

### Installation For Gas Powered Models



# Installation Safety Precautions


## ⚠ Warning

### Receiver (receiver antenna)

- ⊘ Do not cut or bundle the receiver antenna wire.
- ⊘ Do not bundle the receiver antenna wire together with the motor controller lead wire.
- ❗ Keep the receiver antenna wire at least 1cm away from motor, battery, and other wiring carrying heavy current.
- ❗ Install the receiver antenna holder as closely as possible to the receiver.

If the antenna wire is cut, bundled, or routed near a noise source, the receiving sensitivity will drop, the running (sailing) range will decrease, and you may lose control of the model.

\*Noise is transmitted through metal, carbon, and other conductive material, so keep the receiver antenna wire away from such parts.



Install the receiver as far away as possible from the battery, motor controller, motor, silicon cord and other noise sources. Keep it away from the antenna wire, in particular.

Installation

## Receiver vibration-proofing / waterproofing


(Car)

- ❗ Vibration-proof the receiver by wrapping it in foam rubber or other vibration-absorbing material and mount it with thick double-sided tape.
- ❗ When using the receiver holder supplied with the model kit, mount the holder to the chassis through a rubber grommet.

(Boat)

- ❗ Vibration-proof the receiver by wrapping it in foam rubber or other vibration-absorbing material. Also waterproof the receiver by sealing it in a plastic bag.

If the receiver is exposed to strong vibration and shock, it will operate erroneously due to the invasion of water drops and you may lose control of the model.




## Warning

### Connector Connections

- ❗ Be sure the receiver, servo, battery and connectors are fully and firmly connected.  
If vibration from the model causes a connector to work loose while the model is in operation, you may lose control.


### Servo Installation

- ❗ When you install the servos, always use the rubber grommets provided in servo hardware bags. Mount the servos so they do not directly come in contact with the mount.  
If the servo case comes in direct contact with the mount, vibration will be directly transmitted to the servo.  
If this condition continues for a long time, the servo may be damaged and control will be lost.



### Servo Throw

- ❗ Operate each servo over its full stroke and be sure the linkage does not bind or is loose.  
The continuous application of unreasonable force to a servo may cause damage and excessive battery drain.



## Warning

### Electronic Speed Control


- ❗ Install the heat sinks where they will **not** come in contact with aluminum, carbon fiber or other parts that conduct electricity.

If the FET Amp (Electronic speed control) heat sinks touch other materials that conduct electricity a short circuit could occur. This could result in loss of control and damage to the system.

### Motor Noise Suppression

- ❗ Always install capacitors to suppress noise when electric motors are used.

If capacitors are not properly installed you could experience erratic operation and reduced range as well as loss of control.



Motors with no suppressor capacitors, or inadequate suppression, may cause the receiver to malfunction. Always solder the capacitors supplied to your motor.

The Schottky diode improves the efficiency of the speed control / motor combination and provides extra protection to the brake FETs. The white ring must always face the positive side.

### Other Noise Suppression Methods

- ❗ Be sure there are no metal parts in your model which under vibration can come in contact with other metal parts.


Metal to metal contacts under vibration will emit a high frequency noise that will affect the receiver's performance. You could experience erratic operation and reduced range as well as loss of control.

## Preparations (Transmitter)

Before setting the Transmitter functions, check and set items next.

### (Display when power switch turned on)

When the power switch is turned on, the currently selected model number is displayed. Check if this number is the model number you want to set-up. To change the model number, use the Model Select function (See page 39).



### Receiver Type Check (RX MODE)


This mode sets the RX type of the transmitter to match the receiver and servos used.

The T4PLS transmitter uses the telemetry type T-FHSS ("TFH") system.


It can also use the conventional FHSS and S-FHSS ("SFH") systems. Because the R304SB receiver supplied with the T4PLS uses the telemetry type T-FHSS ("TFH") system, its RX type must be set to the T-FHSS high speed mode ("TFH-HI") or the T-FHSS normal mode ("TFH-NR"). Never use analog servos when the RX type was set to the T-FHSS ("TFH") 2.4GHZ system high speed mode "TFH-HI" or the S-FHSS (SFH) high speed mode "SFH-HI". The servos may be damaged. For example, if analog servos are used with a telemetry type T-FHSS receiver (R304SB, etc.), the RX type must be set to "TFH-NR", and if analog servos are used with an S-FHSS receiver (R2104GF, R204FG-E, etc.), the RX type must be set to S-FHSS ("SFH-NR") system normal mode or FHSS ("FHSS") system. When using digital servos (including BLS Series brushless servos), any RX type can be used.

When a dedicated FHSS receiver (R603GF/R2004GF) is used, it will not operate if the RX type is not set to "FHSS".

If the receiver used and the RX type settings are different, change the RX type using the "RX MODE" function. Which RX type is set can be checked at the HOME screen.




T-FHSS Normal speed  
T-FH (NORM)




T-FHSS High speed  
T-FH (HIGH)



S-FHSS Normal speed  
S-FH (NORM)



S-FHSS High speed  
S-FH (HIGH)




FHSS


## Receiver Type Change & How To Link

The first operation described below sets the RX type. Next, the transmitter and receiver are linked and the transmitter ID number is memorized at the receiver so that signals from other transmitters will not be received. The telemetry type T-FHSS also simultaneously memorizes the ID number of the receiver at the transmitter so that data from other receivers will not be received.

The RX type setting and transmitter and receiver linking methods are described here. Refer to the figure at the right for the edit buttons used.




**1** Set the transmitter power switch to DISP. Select "RX Setting" by (JOG) button up or down operation, and display the "RX MODE" screen by pressing the (JOG) button.



**2** Move the cursor to "TYPE: ----" by (JOG) button up or down operation, and select the RX type with the (+) button or (-) button.

When the (JOG) button is pressed for approximately 1 second, an electronic sound is generated and setting ends.




\*When using an FHSS (R603GF/R2004F, etc.) or S-FHSS(SFH) system (R2104GF, R204GF-E, etc.) receiver, after the end of setting up to here set the transmitter power switch to OFF and go to "**Receivers other than T-FHSS**" on page 32.


**3** Bring the transmitter and receiver to within 50cm of each other (do not allow the antennae to touch) and turn on the receiver power.

**4** Move the cursor to "LINK: EXE" by transmitter T4PLS's (JOG) button up or down operation.

When the (JOG) button is pressed for approximately 1 second, "PUSH RX LINK SW" appears on the screen and 20 seconds countdown begins. Countdown can be canceled at any time by button up down or left right operation.



**5** During 20 seconds countdown, push up the receiver side tact switch for approximately 2 seconds. The LED will begin to blink red. After the receiver LED switches from blinking red to green-red steady light, the T4PLS generates an electronic beeping sound, and "LINK:OK" and "COMPLETE!" appear on the screen, reading of the mutual IDs ends and the memorized receiver ID number appears on the T4PLS screen. If an error screen was displayed, linking failed. Retry linking. If the transmitter and receiver are linked normally, set the power switch to the OFF position and then return it to the PWR ON position. If the receiver LED lights green, linking was successful. Actually check servo operation.



Initial Set-Up

\*The T4PLS and a telemetry type T-FHSS receiver (R304SB, etc.) mutually memorize the combined ID linked last at each model memory.


Since the T4PLS can memorize only 1 receiver ID at each model memory, multiple T-FHSS receivers cannot be used with the same model memory. Besides, when changing the receiver at the same model memory, re-link the previously linked receiver.

When using multiple telemetry type T-FHSS receivers, link and combine them with each T4PLS model memory.

However, multiple receivers cannot be linked to multiple model memories.

The telemetry function communications status can be checked at the T4PLS HOME screen.

The telemetry ON/OFF and communication status can be checked at the HOME screen.




- Telemetry function :ON
- Receiver ID setting complete
- Data receiving sensitivity display
- **TH:OFF** shows that data cannot be received because it is outside the data receiving range or because of the effects of an obstruction or the receiver power is OFF after receiver ID check.

- Telemetry function :ON
- Receiver ID before setting or ID mismatch
- When the receiver ID is set, before ID check in the receiver power OFF stat

Telemetry function :OFF

## Receivers Other Than T-FHSS

- 1 Bring the transmitter and the receiver close to each other, within 20 inches (half meter).
- 2 Turn on the transmitter.
- 3 Turn on the receiver.
- 4 Push the tactile switch of the receiver.  
When the link is complete, the LED in the receiver changes to solid green.



### Precaution:

If there are many Futaba 2.4GHz systems (T-FHSS/ S-FHSS/ FHSS) turned on in close proximity to your receiver might not link to your transmitter. In this case, even if the receiver's LED stays solid green, unfortunately the receiver might have established a link to one of other transmitters. This is very dangerous if you do not notice this situation. In order to avoid the problem, we strongly recommend you to double-check whether your receiver is really under control by your transmitter by giving the stick input and then checking the servo response.

\*Please refer to the table below for LED status vs receiver's condition.

LED status vs receiver's condition:

No signal reception	Red : On
Receiving signals	Green: On
Receiving signals, but ID is unmatched.	Green: Blink <sup>*1</sup> (T-FHSS ,Red : On)
Unrecoverable failure (EEPROM,etc.)	LED: Red and Green turn on alternately


\*1: LED could be change to red during intermittently during data processing.

## ⚠ Warning

- 1 After the linking is done, please cycle receiver power and check if the receiver to be linked is really under the control of your transmitter.
- 2 Do not perform the linking procedure with motor's main wire connected or the engine operating as it may result in serious injury.

# Throttle Mode Check

The throttle servo travel can be set to 5:5 or 7:3 for throttle trigger operation as required by the throttle mode function (page 80).




# Trims Initial Set-Up

## - Steering trim (DT1) check

On the initial set-up, steering trim is assigned to the DT1 trim lever above the steering wheel. Operate the lever and make sure the marker moves on the ST graph. If default has been changed, test steering trim in its new location. After checking the trim, set the trim display to the center (N) position.

## - Throttle trim (DT2) check

On the initial set-up, throttle trim is assigned to the DT2 trim lever on the left side of the steering wheel. Operate the lever and make sure the marker moves on the TH graph. If the default has been changed, test the throttle trim in its new location. After checking the trim, set the trim display to the center (N) position.




## - Steering dual rate (DT3) check

At initial set-up, steering dual rate (D/R) is assigned to the DT3 lever, at the grip of the transmitter. Operate the DT3 and check if the D/R value displayed on the screen changes. After checking D/R, set the steering dual rate to 100%.

## - Throttle ATL (DT4) check

At initial setting, throttle ATL (ATL) is assigned to the DT4 lever, below the DT3. Operate the DT4 and check if the ATL value displayed on the screen changes. After checking ATL, set throttle ATL to 100%.



Initial Set-Up



### (Set-Up Procedure When Installed In a Car)

When installing the servos in a car, performing function set-up in the following order is recommended.

- 1** Perform step 1 to Trims Initial Set-Up of Preparations on the preceding page.
- 2** Set the servo direction of operation using the Reverse function. (p.44)
  - The servo installation method and linkage direction depend on the kit. Therefore, the servo operation direction may have to be reversed relative to transmitter operation. Before installing the servo, check the operating direction and set it using the Reverse function.
- 3** Set the subtrim and adjust the servo neutral point. (p.45)
- 4** Set the trigger travel by adjusting the throttle trigger mechanical ATL to your liking. (p.22)
  - When the stroke was adjusted, compensate the throttle by adjuster function (See page105).
- 5** Set EPA of each channel and adjust the servo throw (travel). (p.46)


## Operation Of Screen

In this instruction manual, Edit Buttons are represented by the symbols shown below. The (JOG) button can be operated in the 4 directions up, down, left, and right.



## Calling The Menu Screen

Refer to the map below for the method of displaying the function setting menu screen from the PWR ON initial screen or DISP (display) screen and the method of returning from the menu screen to the PWR ON initial screen or DISP (display) screen.




On the DISP MENU screen, move the cursor to "FUNC MENU" by (JOG) button up or down operation and press the button.

## Selecting Items On The Menu Screen

The item indicated by the reverse displayed cursor on the screen is selected.


The cursor is moved by (JOG) button in up or down movements. The cursor movement figure shown below is an example of the MENU 1 screen. However, movement of the cursor is the same in all of the screens.

For instance, if the (JOG) button is pressed when the cursor is at the end point (EPA) on the MENU 1 screen, the end point (END POINT) function setting screen appears.



## Value Of Each Function And Changing The Set Value


Values, settings, and other data on all the function setting screens are changed with the (+) and (-) buttons.




# Basic Menu Japanese Katakana Character Display

On the system menu, the basic menu screen shown below can be displayed in Japanese katakana characters.

"KATAKANA" characters	Alphabetic characters
EXP	EXP
スピード	SPEED
TH A.B.S	TH A.B.S
アクセレーション	TH ACCEL
エンドポイント	END POINT
トリム	TRIM
リバース	REVERSE
D/R ATL	D/R ATL
フェイルセーフ	FAIL SFE
CH3 /CH4	CH3 /CH4
モデル	MODEL
モデル ネーム	MDL NAME
ブレーキ MIX	BRAKE MIX
PROG MIX	PROG MIX
4WS	4WS
デュアルESC	DUAL ESC
ジャイロMIX	GYRO MIX
CPS MIX	CPS MIX
THモード	TH MODE
SW/ダイヤル	SW/DIAL
タイマー	TIMER
ラップリスト	LAP LIST
システム	SYSTEM
アジャスター	ADJUSTER




(MENU 1 screen)




(MENU 2 screen)

## Changing the character



After changing the setting, return to the MENU2 screen by pressing the (JOG) button or return to the HOME screen by selecting [RT] and pressing the (JOG) button.



## Function List

Function Abbreviation	Description Of Function	Page No
<b>RX MODE</b>	Receiver type selection/linking with telemetry type T-FHSS system receiver	P-29
<b>MODEL</b>	Model memory call/ Model memory copy/ Model memory reset	P-39
<b>MDL NAME</b>	Model memory name set/modify, username set/modify	P-43
<b>REVERSE</b>	Servo operation reversing	P-44
<b>SUBTRIM</b>	Servo center position fine adjustment	P-45
<b>END POINT</b>	End point adjustment	P-46
<b>FAIL SAFE</b>	Fail safe, battery fail safe	P-49
<b>EXP</b>	Steering curve adjustment/ Throttle curve adjustment	P-51
<b>SPEED</b>	Steering servo delay/ Throttle servo delay	P-54
<b>TH ACCEL</b>	Reduces the "lag time" of the throttle from the neutral position.	P-57
<b>TH A.B.S</b>	Pumping brake	P-59
<b>CH3/CH4</b>	Channel 3&4 servos operation position set/check	P-63
<b>D/R ATL</b>	Steering angle adjustment while running/ Brake side adjustment	P-64
<b>SW/DIAL</b>	Selection of functions operated by switch, digital dial and digital trim	P-65
<b>BRAKE MIX</b>	Front and rear independent brake control for 1/5GP car, etc.	P-68
<b>PROG MIX</b>	Programmable mixing between arbitrary channels	P-70
<b>4WS MIX</b>	4WS mixing	P-72
<b>DUAL ESC</b>	Front and rear ESCs mixing	P-74
<b>GYRO ESC</b>	The sensitivity of Futaba car rate gyros can be adjusted.	P-76
<b>CPS ESC</b>	The CPS-1 of Futaba LED controller can be adjusted.	P-78
<b>TH MODE</b>	Throttle servo forward side and brake side operation rate setting/ Neutral brake/ Idle up at engine start/ engine cut off by switch	P-80
<b>MC LINK</b>	MC851C/602C/402CR/950CR/940CR/960CR Link software setting function	P-86
<b>MDL TRANS</b>	Data copy from T4PLS to another T4PLS	P-92
<b>TIMER</b>	Up, down, or lap timer	P-94
<b>LAP LIST</b>	Lap timer data (lap time, total time) check	P-100
<b>SYSTEM</b>	LCD contrast/backlight/Battery type/buzzer/power off forgotten alarm/Basic menu character display /HOME screen display mode	P-101
<b>ADJUSTR</b>	Steering wheel and throttle trigger correction	P-105
<b>TELEMETRY</b>	Displays the status during operation, of each sensor unit and records the status in a data log.	P-107

## Model "MODEL"

Forty model data (data for 40 R/C cars) can be saved in the T4PLS transmitter. This menu selects the model, copies data between models.


### Model Menu Display

The MENU 1 screen is displayed by (JOG) button up, down, left, or right operation at the HOME screen.


The display can be switched to the MODEL screen by selecting "MODEL" and performing (JOG) button up or down operation.

The display can be switched to the HOME screen by switching from the MODEL menu screen to the MENU 1 screen by pressing the (JOG) button and then pressing the (-) button at the MENU 1 screen.

When the (JOG) button is pressed from the MODEL menu screen, the display switches to the MENU1 screen and can then be switched to the HOME screen by pressing the (-) button from the MENU1 screen.



- Setting item**
- SELECT :Model selection
  - COPY :Model copy
  - RESET :Model reset



Function

# Model Selection "SELECT"

Forty model data (model data for 40 R/C cars) can be saved in the 4PLS transmitter and used when the relevant model data is called.

## Using the model select function

- Display the MODEL screen by referring to P39.

- 1 (Selection of model select)  
Move the cursor to "SELECT" by the (JOG) button up or down operation.

```

MODEL [RT]
No. 01
MODEL-0001
ID=13010000

SELECT : 01
COPY: 01 → 01
RESET: EXE
    
```

→ Move the cursor to select model # with the (JOG) button.

- 2 (Model #. selection)  
Select the model number with the (+) or (-) button. "01" ~ "40" are displayed.

```

MODEL [RT]
No. 01
MODEL-0001
ID=13010000

MODEL-0002
(NO LINK)

SELECT : 02
COPY: 01 → 01
RESET: EXE
    
```

Model #.  
01~40

→ Select model # with the (+) or (-) button.

- 3 (Model select execution)  
Press the (JOG) buttons simultaneously for 1 second. A beeping sound is generated and the model is selected.

```

MODEL [RT]
No. 02
MODEL-0002
(NO LINK)

SELECT : 02
COPY: 02 → 02
RESET: EXE

COMPLETE!
    
```

→ Modified model # and model name

→ "COMPLETE!" is displayed.

- Model change is complete when the model No. and model name on the screen change and "COMPLETE!" is displayed .

- 4 When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button.

```

* MENU 1 *

[RT]
▶EXP
▶SPEED
▶TH A.B.S
▶TH ACCEL
▶END POINT
▶SUBTRIM
▶REVERSE
▶D/R ATL
▶FAIL SAFE
▶CH3/CH4

MODEL
MDL NAME
    
```

When the model changed, use after turning the transmitter power off and on.

Function

# Model Copy "COPY"

The contents of the currently selected model data can be copied to another model.

## Using the model copy function

- Display the MODEL screen by referring to P39.

### 1 (Selection of model copy)

Move the cursor to "COPY" by the (JOG) button up or down operation.

```
MODEL [RT]
No. 01
MODEL-0001
ID=130100000

SELECT : 01
COPY: 01 → 01
RESET: EXE
```

Move the cursor to "COPY" with the (JOG) button.

### 2 (Model #. selection)

Select the copy destination model number with the (+) or (-) button. "01" ~ "40" are displayed.

```
MODEL [RT]
No. 01
MODEL-0001
ID=130100000

MODEL-0002

SELECT : 01
COPY: 01 → 02
RESET: EXE
```

Model #.  
01~40

The copy destination model # with the (+) or (-) button.

### 3 (Model copy execution)

Press the (JOG) buttons for about 1 second. A beeping sound is generated and the model is selected.

```
MODEL [RT]
No. 01
MODEL-0001
ID=130100000

MODEL-0001

SELECT : 01
COPY: 01 → 02
RESET: EXE

COMPLETE!
```

Model name is also copied.

"COMPLETE!" is displayed.

-Copying is complete when "COMPLETE!" is displayed on the screen.

### 4 When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button.

```
* MENU 1 *
[RT]
▶EXP
▶SPEED
▶TH A.B.S
▶TH ACCEL
▶END POINT
▶SUBTRIM
▶REVERSE
▶D/R ATL
▶FAIL SAFE
▶CH3/CH4

▶MODEL
▶MDL NAME
```



Function

# Model Reset "RESET"

This function resets and initializes the contents of the currently selected model data. However, the adjuster function (ADJUSTER), system setting (SYSTEM), and type of receiver mode (TYPE) are not initialized.

## Using the model reset function

- Display the MODEL screen by referring to P39.

- 1 (Selection of model reset)  
Move the cursor to "RESET" by the (JOG) button up or down operation.

```

MODEL [RT]
NO. 01
MODEL-0001
ID=13010000

SELECT : 01
COPY: 01 → 01
RESET: EXE
    
```

→ Move the cursor to "RESET" with the (JOG) button.

- 2 (Model reset execution)  
Press the (JOG) buttons for about 1 second. A beeping sound is generated and the model is selected.  
  
-Resetting is complete when "COMPLETE!" is displayed on the screen.

```

MODEL [RT]
NO. 01
MODEL-0001
ID=13010000

SELECT : 01
COPY: 01 → 01
RESET: EXE
COMPLETE!
    
```

→ "COMPLETE!" is displayed.

- 3 When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button.

```

* MENU 1 *
[RT]
▶EXP
▶SPEED
▶TH A.B.S
▶TH ACCEL
▶END POINT
▶SUBTRIM
▶REVERSE
▶D/R ATL
▶FAIL SAFE
▶CH3/CH4
MODEL
▶MDL NAME
    
```


The set RX type and T-FHSS receiver ID remain even if the model is reset. The same receiver can be used as is without re-linking

Function

# Model Name "MDL NAME"

This function allows you to assign a ten character name to each model memory and user name.

Display to "MDL NAME" screen by the following method:




When (JOG) button left or right operation is performed from both the left and right ends of the character list, the page (all 3 pages) is changed and the character set is selected.  
(KATAKANA of the 3rd page is displayed when "KANA" is set by the "SYSTEM" function "MENU".)


## Setting the model name and user name

- 1** (Move the cursor to the character you want to change.)  
Select the model name character you want to set or change by moving the cursor by the (+) or (-) button. The selected character blinks.
- 2** (Selecting the character to be used)  
Select the character to be used from the character list at under side of the screen by the (JOG) button up, down, left, or right operation. The selected character blinks. After selecting the character to be used, press the (JOG) button. The character is entered and the model name or user name character row moves to the right.  
Also move the cursor to "RESET" by the (JOG) button up, down, left, or right operation, and press the buttons for about 1 second. A beeping sound is generated and the model name is initialized to the factory setting.
- 3** When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button.

Move the cursor to the character you want to change by (+) or (-) button.



Select the character by (JOG) button.



Move the cursor to "RESET" by the (JOG) button up or down operation.

Function


# Servo Reverse "REVERSE"

(All channel)

This function reverses the direction of operation of the servos related to transmitter steering, throttle, and channel 3 /4 operation.

However, when the position set by trim or subtrim shifts from the center, the center becomes the opposite side.

Display to "REVERSE" screen by the following method:



**Setting item**

- STR :Steering (1st channel)
- THR :Throttle (2nd channel)
- CH3 :3rd channel
- CH4 :4th channel

## Servo Reverse Function Setting

(Preparation)


- Select the channel to be set by the (JOG) button up or down operation.

### 1 (Servo reverse setting)

Use the (+) or (-) button to reverse the servo operation direction.

NOR/REV can also be set by (JOG) button left or right operation

(Each channel can be set similarly.)



Move the cursor to "STR, THR, CH3 and CH4" with the (JOG) button.

**Select button**

- Select with the (+) or (-) buttons.

Function



### 2 When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button.

# Subtrim "SUBTRIM"


(All channel)

Use this function to adjust the neutral position of the steering, throttle, channel 3 and channel 4 servos.

\*Subtrim adjusts the entire range of the servo in the set direction.



Display to "REVERSE" screen by the following method:



**Steering and throttle center trim**  
When assigning DT1, DT2, or other digital trimming to another function, make adjustments at this screen.

## Subtrim adjustment

(Preparation)

- Set the steering and throttle digital trims to the neutral "0" position. Set CH3 and CH4 to the center "0" position.


### Setting item

- STR :Steering (1st channel)
- THR :Throttle (2nd channel)
- CH3 :3rd channel
- CH4 :4th channel

### 1 (Subtrim adjustment)

Use the (+) or (-) button to adjust the center.

(Each channel can be set similarly.)



Move the cursor to "STR, THR, CH3 and CH4" with the (JOG) button.

### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

### Subtrim

- ST :L100~R100
- TH :B100~F100
- CH3 :-100~+100
- CH4 :-100~+100
- Initial value : 0

- When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button.

# End Point Adjuster "END POINT"

(All channel)

Use this when performing left and right end point adjustments, throttle high side/brake side operation amount adjustment, channel 3 and channel 4 servo up side/down side operation amount adjustment during linkage.

- Correct the maximum steering angle for left and right steering angles when there is a difference in the turning radius due to the characteristics, etc. of the vehicle.

## Maximum steering angle

The EPA function basically determines the maximum steering angle of each channel. The functions shown below may have been adjusted or the operating range set by EPA function may be exceeded. Check the linkage each time the following functions are adjusted.

- Sub trim (all channels)..... P45
- Program mixing slave side (all channels) ..... P70
- Idle up (throttle) ..... P81
- Throttle dff, Engine Cut (throttle)..... P83
- Throttle acceration (throttle)..... P57

## ATL trim

ATL trim allows adjustment of the brake side operation amount during operation. Therefore, when the operating angle is adjusted with throttle EPA, ATL trim must also be taken into account.

### Warning


- ❗ Operate each servo over its full stroke and be sure the linkage does not bind or is not loose.

The continuous application of unreasonable force to a servo may cause damage and excessive battery drain.



Decide the EPA value at the contact point.

Adjust the steering servo so that unreasonable force is not applied to the servo by the chassis at maximum servo travel.




Adjust the throttle servo so that unreasonable force is not applied when the engine carburetor is fully open, fully closed, and the brakes are applied fully.

If the brakes overheat while running, their ability to function properly decreases. Before running, adjust the suitable maximum servo travel so that unreasonable force is not applied even when the servo travel is increased while running.

Function

Display to "END POINT" screen by the following method:



**Setting item selection**

**(Steering and Throttle direction)**

- The direction (STR LFT and STR RGT) linked with the steering wheel is switched.
- The direction (THR FWD and THR BRK) linked with the throttle trigger is switched.



**Setting item (channel and direction)**

- STR LFT :Steering (left side)
- STR RGT :Steering (right side)
- THR FWD :Throttle (foward side)
- THR BRK :Throttle (brake side)
- CH3/CH4 UP :3rd or 4th channel (up side)
- CH3/CH4 DWN :3rd or 4th channel (down side)

**Steering (END POINT) adjustment**


(Preparation)

- Before setup of the steering end point adjustment (END POINT), set the steering D/R rever (initial setup: DT3) to the maximum steering angle position 100%.
- Select the setting item "RGT" by the (JOG) button up, down, left, or right operation and make the following adjustments:




**1 Steering (left side) adjustment**

Turn the steering wheel fully to the left and use the (+) or (-) buttons to adjust the steering angle.



**2 Steering (right side) adjustment**

Turn the steering wheel fully to the right and use the (+) or (-) buttons to adjust the steering angle.



**3** When ending, return to the MENU1 screen by pressing the (JOG) button.

**Adjust button**

Adjust with the (+) and (-) buttons.

- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

**Steering EPA**


- STR LFT :0~120
- STR RGT :0~120
- Initial value :100

Function

## Throttle (END POINT) adjustment


(Preparation)

- Before setting the throttle end point adjustment (END POINT), set the throttle ATL lever (initial setup: DT4) to the maximum throttle angle position 100%.
- Select the setting item "FWD" by the (JOG) button up or down operation and make the following adjustments:



### 1 Throttle (forward side) adjustment

Pull the throttle trigger fully to the high side and use the (+) or (-) buttons to adjust the throttle angle. However, when using an FET amp, set to 100%.




### 2 Throttle (brake side/reverse side) adjustment

Move the throttle trigger fully to the brake side and use the (+) or (-) buttons to adjust the throttle angle. However, when using an ESC, set to 100%.



### 3 When ending, return to the MENU1 screen by pressing the (JOG) button.



#### Adjust button

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

#### Throttle EPA

THR FWD :0~120  
THR BRK :0~120  
Initial value :100

## 3rd & 4th channel servo (END POINT) adjustment


### 1 3rd/4th channel servo (up side) adjustment

Select the setting item "CH3 or CH4 UP" by the (JOG) button up or down operation, and set the 3rd or 4th channel dial fully to the up side (+ side) and use the (+) or (-) buttons to adjust the servo angle.

### 2 3rd/4th channel servo (down side) adjustment

Select the setting item "CH3 or CH4 DWN" by the (JOG) button up or down operation, and set the 3rd or 4th channel dial fully to the up side (- side) and use the (+) or (-) buttons to adjust the servo angle.

### 3 When ending, return to the MENU1 screen by pressing the (JOG) button.



#### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

#### 3rd & 4th channel EPA

CH3/CH4 UP :0~120  
CH3/CH4 DWN :0~120  
Initial value :100

# Fail Safe Function "FAIL SAFE"

(All channel)

## Fail Safe Mode (F/S)

This function moves each servo to a preset position when the receiver cannot receive the signals from the transmitter for some reason.

-When the condition set at "FHSS" is Rx type (P29), fail safe (F/S) can be set only for throttle (TH). Other channels are set to the normal mode.

-The fail safe data is transferred from the transmitter to the receiver 10 seconds after the transmitter power was turned on. The data is transferred every 5 seconds after that. Be careful because normally the transmitter power is turned on first and the receiver power is turned on next and the data is transferred for approximately 10 seconds after the receiver power is turned on.

-For gasoline engine cars, for safety we recommend that this fail safe function be used to set the throttle channel in the direction in which the brakes are applied.

## Hold mode (HOLD)

This function holds the receiver in its position immediately before reception was lost. It is the T-FHSS typ (R304SB...etc) and the S-FHSS type (R2104GF...etc) receiver only function. When the receiver used is the R603GF/R2004GF and other FHSS type, this function cannot be used because the receiver type is set to "FHSS" by Rx type setting

## Off mode (OFF)

This function stops output of signals to the servos and places the servos into the free state when the receiver cannot receive.

The F/S, HOLD, and OFF modes are automatically reset when signals from the transmitter can be received again.


## Battery fail safe function (BFS)

If the receiver battery voltage drops below a certain value when this function is enabled, the throttle servo moves to the position set by fail safe function. When the battery voltage recovers, the battery fail safe function is automatically reset.

-This function cannot be used when the throttle (TH) is not set to fail safe (F/S).

-This function is for the T-FHSS typ (R304SB...etc) and the S-FHSS type (R2104GF...etc) receiver only. It cannot be used with the R603GF and R2004FG and other FHSS type.

Display to "FAIL SAFE" screen by the following method:



## Fail safe mode selection

(Preparation)

- Select the channels "MODE" to be set by the (JOG) button up, down, left, or right operation.


### 1 (Mode selection)

Select the mode by (+) or (-) button.

(Each channel can be individually set.)

### 2 When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button. When setting fail safe, set the servo position by the following method.

When setting fail safe, set the servo position by the following method.



#### F/S mode

OFF, HOLD, F/S

#### F/S mode selection

- Select with the (+) or (-) buttons.

#### F/S position setup button

- The (JOG) buttons is pressed for about 1 second.


## Fail safe function setup

### 1 (Servo position setup)

When the fail safe function operates, select the setting item "POSI" by the (JOG) button. The steering wheel, the throttle trigger or 3rd, 4th channel dial remains in the desired operation position. When the (JOG) button is pressed for about 1 second, the servo position is displayed and you can confirm that the function was set.

(Each channel can be set similarly.)

### 2 When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button.



## Battery fail safe function ON/OFF (T-FHSS/ S-FHSS)

(Preparation)


- Select the setting item by the (JOG) button. For Battery F/S function ON/OFF, select "OFF" or "ACT" of "B-FS".

For voltage setting, select RX\*\*v. (The T-FHSS system only. )

The S-FHSS system is fixed at 3.8v.

### 1 (Battery fail safe function ACT/OFF)

BATT-F/S function ACT/OFF and voltage setting which activates the B-F/S function can be switched by (+) or (-) button.



#### Battery fail safe function

OFF, ACT

Initial value: OFF

#### B-F/S Voltage

3.8, 4.0, 4.2, 4.4, 4.6, 4.8, 5.0, 5.3, 5.6, 5.9, 6.2, 6.5, 6.8, 7.1, 7.4(V)

Initial value 3.8v

Example:

Ni-MH /Ni-Cd 4cell---3.8V

Ni-MH /Ni-Cd 6cell---4.4V


LiFe 2cell---4.8V

Li-Po 2cell---5.6V

### 2 When ending, move the cursor to [RT] by the (JOG) button, and return to the MENU1 screen by pressing the (JOG) button.

# Exponential Adjustment "EXP" (Steering/Throttle system)

This function is used to change the sensitivity of the servo around the neutral position. Display to "EXP" screen by the following method:



### Setting item


- STR :Steering
- FWD :Throttle forward side
- BRK :Throttle brake/ reverse side

## STR (Steering EXP)

This function is used to change the sensitivity of the steering servo and around the neutral position. It has no effect on the maximum servo travel.

### Racers Tip

When the setting is not determined, or the characteristics of the model are unknown, start with 0%. (When EXP is set to 0%, servo movement is linear.)




### Steering EXP adjustment

(Preparation)

- On the EXP screen, Select the setting item "STR" by the (JOG) button.

- 1 When you want to quicken steering operation, use the (+) button to adjust the + side. When you want to make steering operation milder, use the (-) button to adjust the - side.



### Adjustment range

-100~0~+100

### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Vertical cursor moves in step with steering wheel operation.

- 2 When ending, return to the MENU1 screen by pressing the (JOG) button.

# FWD (Throttle Forward SideEXP)/ BRK (Throttle Brake Side EXP)

This function makes the throttle forward side and brake side direction servo operation quicker or milder. It has no effect on the servo maximum operation amount.

## Advice

When the course conditions are good and the surface has good grip, set each curve to the + side (quick side). When the road surface is slippery and the drive wheels do not grip it, set each curve to the - minus (mild) side.

## Throttle forward side EXP adjustment

(Preparation)

- On the EXP screen make the following adjustments:

**1** Select the setting item "FWD" by the (JOG) button up or down operation.

Use the p(+) button to adjust for a faster throttle response or use the (-) button for a slower or milder throttle response.



### Adjustment range

-100 ~ 0 ~ +100%

### Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.



Vertical cursor moves in step with throttle trigger operation.

**2** When ending, return to the MENU1 screen by pressing the (JOG) button.

## Throttle brake side EXP adjustment

(Preparation)

- On the EXP screen make the following adjustments:

**1** Select the setting item "BRK" by the (JOG) button up or down operation.

Use the (+) button to adjust for a faster throttle response or use the (-) button for a slower or milder throttle response.



### Adjustment range

-100 ~ 0 ~ +100%

### Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.



**2** When ending, return to the MENU1 screen by pressing the (JOG) button.

### Dial / Trim Setting


The steering and throttle EXP adjustment (RATE) can be controlled with digital dial or digital trim. With the function select switch dial function. (See page 65)

# Servo Speed "SPEED"

(Steering system)

This function is used to change the servo speed.

Display to "SPEED" screen by the following method:




**Setting item**

STR TURN	:Steering turn side
STR RETN	:Steering return side
THR TURN	:Throttle turn side

## STR (Steering Speed)


Quick steering operation will cause momentary understeering, loss of speed, or spinning. This function is effective in such cases.



Function

### Operation

- This function limits the maximum speed of the steering servo. (Delay function)
- The steering speed when the steering wheel is operated (TURN direction) and returned (RETN direction) can be independently set.
- If the steering wheel is turned slower than the set speed, the steering servo is not affected.




## Steering Speed adjustment

(Preparation)

- On the SPEED screen make the following adjustments:

### 1 "TURN" direction adjustment

On the SPEED screen, Select the setting item STR "TURN" by the (JOG) button up or down operation and use the (+) or (-) buttons to adjust the delay amount.



#### Adjustment range

1~100% (each direction)  
At 100%, there is no delay.





Servo operation is delayed.

#### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

### 2 "RETN" direction adjustment

Select the setting item STR "RETN" by the (JOG) button up or down operation and use the (+) or (-) buttons to adjust the delay amount.



#### Adjustment range

1~100% (each direction)  
At 100%, there is no delay.



Servo operation is delayed.

#### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

3 When ending, return to the MENU1 screen by pressing the (JOG) button.

### Setting example (Steering servo: BLS451 / BLS351) . . . (Setting criteria)

- Onroad TURN side: Approx. 50~80% RETURN side: Approx. 60~100%
- Offroad TURN side: Approx. 70~100% RETURN side: Approx. 80~100%

### Dial / Trim Setting

The steering speed adjustment "TURN" and "RETN" can be controlled with digital dial or digital trim. With the function select switch dial function. (See page 65)

## THR (Throttle Speed)

Sudden throttle trigger operation on a slippery road only causes the wheels to spin and the vehicle cannot accelerate smoothly. Setting the throttle speed function reduces wasteful battery consumption while at the same time permitting smooth, enjoyable operation.



With "SPEED": Quick start without skidding




Without "SPEED": Slow start due to skidding

### Operation

-Throttle servo (ESC) operation is delayed so that the drive wheels will not spin even if the throttle trigger is operated more than necessary.

This delay function is not performed when the throttle trigger is returned and at brake operation.




### Throttle Speed adjustment

(Preparation)

- On the SPEED screen make the following adjustments:

#### 1 (Delay adjustment)

On the SPEED screen, Select the setting item THR "TURN" by the (JOG) button up or down operation and use the (+) or (-) buttons to adjust the delay amount.



#### Adjustment range

1~100%

At 100%, there is no delay.

1% 100%



Servo operation is delayed.

#### Adjust button

- Adjust with the (+) and (-) buttons.

- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

2 When ending, return to the MENU1 screen by pressing the (JOG) button.

### Dial / Trim Setting

The throttle speed adjustment can be controlled with digital dial or digital trim. With the function select switch dial function. (See page 65)


# Throttle Acceleration "TH ACCEL"

(Throttle system)

The servo will jump to the input position at its maximum possible speed. Unlike exponential, which adjusts the whole throttle movement into a curve, throttle acceleration simply "jumps" away from neutral and then leaves the remaining response linear.

## Operation

- Operation near the throttle trigger neutral position becomes a sharp rise.
- The forward and brake sides can be set separately.
- When the brake mixing function (p.72) is set, the CH3/CH4 brake can also be set.




## Set value


The standard value (100% point) of this setup affects the operation amount set by throttle EPA function.

## Convenient usage method

For gasoline engine cars, the linkage must have a clearance because one servo controls the engine carburetor and brake. Thus, there is a noticeable time delay at both the forward and brake sides. Sharp response comparable to that of electric motor cars is obtained by reducing this clearance at the transmitter side.



Display to "TH ACCEL" screen by the following method:



### Setup item

- FWR RATE :Forward side acceleration
- BRA RATE :Brake side acceleration

Function


## Throttle acceleration adjustment

(Preparation)

- On the TH ACCEL screen make the following adjustments:

### 1 (Forward acceleration amount adjustment)

Select the setting item FWD "RATE" by the (JOG) button up or down operation and use the (+) and (-) buttons to adjust the acceleration amount.



"0" :No acceleration

"100" :Maximum acceleration (Approximately 1/2 of the forward side throttle angle)

### Forward acceleration amount (FWD)

0~100

Initial value: 0


### Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

### 2 (Brake side acceleration amount adjustment)

Select the setting item BRK "RATE" by the (JOG) button up or down operation and use the (+) and (-) buttons to adjust the acceleration amount.



"0" :No acceleration

"100" :Maximum acceleration (Brake side maximum throttle angle)

### Brake side acceleration amount (BRK)

0~100

Initial value: 0

### Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

4 When ending, return to the MENU1 screen by pressing the (JOG) button.


## Dial / Trim Setting

The throttle acceleration adjustment amount (FWD), (BRK) can be controlled with digital dial or digital trim. With the function select switch dial function. (See page 65)

# A.B.S. Function "TH A.B.S"

(Throttle system)

When the brakes are applied while cornering with a 4 Wheel Drive or other type of vehicle, understeer may occur. The generation of understeer can be eliminated and corners can be smoothly cleared by using this function.



Without A.B.S.



With A.B.S.


## Operation

- When the brakes are applied, the throttle servo will pulse intermittently. This will have the same effect as pumping the brakes in a full size car.
- The brake return amount, delay amount, pulse cycle, and brake duty can be adjusted.

## Operation display

During ABS operation, the LED blinks.

Display "TH A.B.S" screen by the following method:




### Setup items

MODE : Function ON/Off	CYCL : Cycle speed
AB.P : Brake return amount	TG.P : Trigger point
DELY : Delay amount	DUTY : Cycle duty ratio

### - AB.P : Amount of brake return

Sets the rate at which the servo returns versus trigger operation for brake release. When set to 0%, the ABS function is not performed. When set to 50%, the servo returns 50% (1/2) of the trigger operation amount and when set to 100%, the servo returns to the neutral position.



Function

**- DELY : Delay**

Sets the delay from brake operation to ABS operation. When set to 0%, the ABS function is activated without any delay. At 50%, the ABS function is activated after a delay of approximately 1 second and at 100%, the ABS function is activated after a delay of approximately 2 seconds.

**- CYCL : Cycle speed**

Sets the pulse speed (cycle). The smaller the set value, the faster the pulse cycle.

**- TG.P : Trigger point**

Sets the trigger point at which the ABS function begins to operate at brake operation.

**- DUTY : Cycle duty ratio**

Sets the proportion of the time the brakes are applied and the time the brakes are released by pulse operation. The ratio can be set to HIGH, MID or LOW.

**- MODE : Function ON/OFF**

ABS function ON/OFF setting. When using the ABS function, set to "ACT(ON)".

**A.B.S function adjustment**

**1** (Function ON/OFF)

Select the setting item "MODE" by the (JOG) button up or down operation. Set the function to the active state by pressing the (+) or (-) button.

- "INH(OFF)" :Function OFF
- "ACT(ON)" :Function ON
- "ACT(OFF)" :Switch OFF when setting switches

**Select button**


- Select with the (+) or (-) buttons.

**Function ON/OFF (MODE)**

INH(OFF), ACT(ON,OFF)

**2** (Brake return amount adjustment)

Select the setting item "AB.P" by the (JOG) button up or down operation. Use the (+) or (-) button to adjust the return amount.



**Brake return amount (AB.P)**

0 ~ 50 ~ 100  
Initial value: 50

- Brake return amount (AB.P) is influenced by the "EXP" rate on the brake side.

**Adjustment buttons**

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

- "0" :No return
- "50" :Return to the 50% position of the brake operation amount
- "100" :Return to the neutral position.

**3** (Delay amount setup)

Select the setting item "DELY" by the (JOG) button up or down operation. Use the (+) or (-) button to adjust the delay amount.

- "0" :A.B.S. function performed without any delay
- "50" :A.B.S. function performed after an approximate 1 sec delay.
- "100" :A.B.S. function performed after an approximate 2 secs delay.

**Delay amount (DELY)**


0 ~ 100  
Initial value: 0

**Adjustment buttons**

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

#### 4 (Cycle speed adjustment)

Select setting item "CYCL" by the (JOG) button up or down operation. Use the (+) or (-) button to adjust the pulse speed (cycle).



#### Cycle speed (CYCL)

1 ~ 30

Initial value: 10


#### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

- The smaller the set value, the faster the pulse speed.

#### 5 (Trigger point setup)

Select setting item "TG.P" by the (JOG) button up or down operation. Use the (+) or (-) button to adjust the operation point.



#### Trigger point (TG.P)

10 ~ 100

Initial value: 30


#### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

- Sets the throttle trigger position at which the A.B.S. function is performed. The number is the % display with the full brake position made 100.

#### 6 (Cycle duty ratio setup)

Select setting item "DUTY" by the (JOG) button up or down operation. Use the (+) or (-) button to adjust the duty ratio.



#### Duty ratio (DUTY)

LOW - MID - HIGH

Initial value: MID

#### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

"LOW" :Brake application time becomes shortest. (Brakes lock with difficulty)

"HIGH" :Brake application time becomes longest (Brakes lock easily)

(Remark) For low grip, set at the LOW side and for high grip, set at the HIGH side.

7 When ending, return to the MENU1 screen by pressing the (JOG) button.

### Dial / Trim Setting

The brake return amount (AB.P), delay amount (DELY) and cycle (CYCL) can be controlled with digital dial or digital trim, with the function switch dial function. (See page 65)

### Switch setting

Use SW1 or SW2 to switch the A.B.S. function ON/OFF.

See the function select switch dial function (See page 65).

## Fail Safe Unit

When the T4PLS is used with the Futaba fail safe unit (FSU), it will operate as described below. However, FSU-1 cannot be used in the high speed mode.

- When the FSU is connected to the throttle channel, and the A.B.S. function has been activated, the FSU LED will flash each time the servo operates. The reason for this is that the FSU responds to sudden data changes caused by A.B.S. function pumping operation. It does not mean that the fail safe function is activated. The servo will not be affected.

## Example of A.B.S. function setting when BLS351 / BLS352 used (There will be a slight difference depending on the state of the linkage.)

- Basic setting

AB.P: Approx. 30% (If this value is too high, the braking distance will increase.)

CYCL: 5~7

DUTY: (When grip is low: LOW side, when grip is high: HIGH side)

DELY: 10~15%

TG.P: Approx. 70%

- When the wheels lock, or the car spins, when the brakes are applied fully

AB.P: Increase from 30%

DUTY: Shift to "LOW" side

DELY: Reduce the delay

- When the braking effect is poor and the braking distance is long when the brakes are applied fully

AB.P: Decrease from 30%

DUTY: Shift to "HIGH" side

DELY: Increase the delay

## 1/5 scale car and other independent brakes and ABS


ABS can be independently set for the brakes which are controlled by the 3rd CH and 4th CH by using the brake mixing (BRAKE MIX) function described on page 68. For more information, read the brake mixing (BRAKE MIX) item.

The channel 3/4 servo position can be set from the transmitter. When CH3 is assigned to a dial by the switch dial function (p.65), this setting is linked to that dial.

When CH3/4 is not assigned to a dial, it can be set with this screen.

When CH3/4 is assigned to a switch by the switch dial function (p.65), you cannot adjust the CH3/4 via the screen.

Display "CH3/CH4" screen by the following method:



## Rate/position adjustment on channel menu screen

- 1** (Function selection)  
On each CH3/CH4 screen select CH3 "POSI" or CH4 "POSI" by the (JOG) button up or down operation.

---

- 2** (Position setting/rate adjustment)  
Use the (+) and (-) buttons to adjust the channel 3 or channel 4 position.

---

- 3** When ending, return to the MENU1 screen by pressing the (JOG) button.

**Channel 3 position (POSI)**  
**Channel 4 position (POSI)**

0~100%  
Initial value: 0

### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

# Steering Dual Rate/ Throttle ATL "D/R ATL"


## D/R (Steering dual rate)

The steering left and right servo travels are adjusted simultaneously. This setting is linked to transmitter grip dial DT3. When DT3 is assigned another function, dual rate can be adjusted with this screen.

## ATL (Throttle ATL)

This function decreases the set value when the braking effect is strong and increases the set value when the braking effect is weak. This function is linked to transmitter grip dial DT4. When DT4 is assigned another function, this function can be set with this screen.

Display "D/R ATL" screen by the following method:



## Dual rate adjustment

### 1 (Dual rate adjustment)

Select the setting item ST-D/R "RATE" by (JOG) button up or down operation. Adjust the servo travel with the (+) and (-) buttons.

### 2 When ending, return to the MENU1 screen by pressing the (JOG) button.

#### D/R rate (RATE)

0~100%  
Initial value: 100

#### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

## ATL function adjustment

### 1 (Brake amount adjustment)

Select the setting item TH-ATL "RATE" by (JOG) button up or down operation. Adjust the servo travel with the (+) and (-) buttons.

### 2 When ending, return to the MENU1 screen by pressing the (JOG) button.

#### ATL rate (RATE)

0~100%  
Initial value: 100

#### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

# Select Switch Dial Function "SW/ DIAL"


Selection of the function to be performed by digital trim (DT1, DT2, DT3, DT4) dial (DL1) and switch (SW1, SW2).

- The functions that can be assigned to dial, digital trim and switch are listed on the next page.
- The dial and digital trim are step amount can be adjusted. (The relationship between set value and step amount is shown in the table on the next page.)
- The direction of operation of the servos can be reversed. (NOR/REV)
- SW1 alternate operation (operation which switches between ON and OFF each time the switch is pressed) is possible.

NOR (Normal) -ON only while pressed, OFF when released.

ALT (Alternate) -Switched between ON and OFF each time pressed.

Display "SW/DIAL" screen by the following method:



## Function select dial/trim setting

### 1 (Setting dial/trim selection)

Select the dial or trim you want to set by the (JOG) button up or down operation.

### 2 (Function setting)

Select the function with the (+) or (-) button.

- Refer to the list on the next page for the abbreviations of the functions.

#### (Step amount setting)

Select the step amount you want to set by the (JOG) button up or down operation. Use the (+) or (-) button to set the step amount.


- Refer to the next page for the relationship between set value and step amount.

#### (Changing the direction of operation)

Select the Direction of operation you want to set by the (JOG) button up or down operation. Use the (+) or (-) button to trim/dial the direction.

### 3 When ending, return to the MENU1 screen by pressing the (JOG) button.

\*Function selection  
\*Step amount setting  
\*Direction of operation setting



Function

#### Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "2" by pressing the (+) and (-) buttons simultaneously for about 1 second.

## Function select switch setting

### 1 (Setting SW selection)

Select the SW you want to set by the (JOG) button up or down operation.

### 2 (Function setting)

Select the function with the (+) or (-) button.

-Refer to the list for the abbreviations of the functions.

(Changing the SW1 operation system)

Select DIR of <SW1> by the (JOG) button up or down operation. Select ALT or NOR with the (+) or (-) button.

### 3 When ending, return to the MENU2 screen by pressing the (JOG) button.



**Set table functions (DL1, DT1/DT2/DT3)**

Abbreviation used on setup screen	Function name, etc
D/R	Dual rate function
ATL	ATL function
EXP-ST	Steering EXP
EXP-FW	Throttle EXP (Forward side)
EXP-BK	Throttle EXP (Brake side)
SPD-TN	Steering speed (Turn side)
SPD-RN	Steering speed (Return side)
ABS.PS	A.B.S. function (Return amount)
ABS.DL	A.B.S. function (Delay)
CYCLE	A.B.S. function (cycle speed)
ACC-FW	Throttle acceleration (Forward side)
ACC-BK	Throttle acceleration (Brake side)
TH-SPD	Throttle speed
ST-TRM	Steering trim
TH-TRM	Throttle trim
CH3	Channel 3
CH4	Channel 4
SUBTR1	Sub trim (CH1)
SUBTR2	Sub trim (CH2)
SUBTR3	Sub trim (CH3)
SUBTR4	Sub trim (CH4)
IDLE	Idle up function
ESC-RT	Dual ESC mixing (4ch ESC rate)
TH-OFF	Throttle off (engine cut)
PMX-A	Program mixing (RGHT/BRAK/DOWN sides)
PMX-B	Program mixing (LEFT/FWRD/UP sides)
BK3-RT	Brake mixing (3ch brake rate)
BK4-RT	Brake mixing (4th brake rate)
4WS-RT	4WS mixing (3ch steering rate)
ESC-MD	Dual ESC mixing (Drive mode select)
GYRO	Gyro mixing (Gain rate)
OFF	Not used

## Adjust button

Adjust with the (+) and (-) buttons.

SW1 function selection  
Direction of operation setting



SW2 function selection  
ON/OFF position is displayed.

## Relationship between set value and step amount

(Setting range: 1~10, 20, 30, 40, 50, 100, 2P)

-Steering trim/throttle trim


When set to the minimum "1", the total trim operating width is 200 clicks. For "100", the total operating width is 2 clicks and for 2P, the total operating width is 1 click.

-Rate, etc. setting

This is the % value which is operated by 1 click relative to the set value of each rate. Since the total operating width of functions having a rate of -100~0~+100 is 200%, when set to "100", the total operating width is 2 clicks. Since the total operating width of functions with a 0~100 rate is 100%, "100" and 2P are operated by 1 click.

-Channel 3/4

When set to the minimum "1", the total operating width of channel 3 is 200 clicks. For "100", the total operating width is 2 clicks and 2P is operated by 1 click.




Set table functions (SW1)	
Abbreviation used on setup screen	Function name, etc
NT-BRK	Neutral brake function ON/OFF
ABS	A.B.S function ON/OFF
IDLE	Idle up function ON/OFF
PRGMIX	Program mixing function ON/OFF
TH-OFF	Throttle off (engine cut) function ON/OFF
CH3	channel 3
CH4	channel 4
4WS MIX	4WS mixing type select
TIMER	Timer function start/stop
LOGGER	Telemetry log start/stop
GYRO	Switching GYRO mode
OFF	Not used

Set table functions (SW2)	
Abbreviation used on setup screen	Function name, etc
NT-BRK	Neutral brake function ON/OFF
ABS	A.B.S function ON/OFF
IDLE	Idle up function ON/OFF
PRGMIX	Program mixing function ON/OFF
TH-OFF	Throttle off (engine cut) function ON/OFF
CH3	channel 3
CH4	channel 4
OFF	Not used

Function

# Brake Mixing "BRAKE MIX" (Throttle, 3rd /4th channel system)

This function is used when the front and rear brakes must be adjusted independently such as a 1/5 scale GP car. This mixing uses the 2nd CH for the rear brakes and the 3rd or 4th CH for the front brakes, or controls the front brakes with the 3rd CH and 4th CH servos, or controls the 2nd CH by independent throttle and controls the rear and front brakes with the 3rd CH and 4th CH.




## Operation

- When braking, mixing is applied to 2nd CH→3rd CH, 4th CH.
- 3rd CH and 4th CH brake amount, 2nd CH, 3rd CH, and 4th CH brake delay, and 3rd CH and 4th CH brake ABS can be set.

## CH3/4 brake ABS function

The ABS function can be used independently at the CH3 and CH4 sides even when the CH2 side ABS function is OFF. The amount of pumping speed (CYCL), operation point (TG.P), and duty ratio (DUTY) can be set in common with the CH2 side ABS function. (CH3 and CH4 brake return (AB.P) is fixed at 50.)

Display "SW/DIAL" screen by the following method:



### Setup item

<CH3>	<CH4>	<CH2>
MODE : Brake function ON/OFF	MODE : Brake function ON/OFF	DELY : Delay amount
RATE : Brake rate	RATE : Brake rate	
DELY : Delay amount	DELY : Delay amount	
ABS : ABS. function ON/OFF	ABS : ABS. function ON/OFF	

## Brake mixing adjustment

### 1 (Brake mixing function ON/OFF)

Using the (JOG) button, select "MODE" of <CH3> for CH3 brake and "MODE" of <CH4> for CH 4 brake.

Use the (+) or (-) key and set the function to the "ACT" state.

"INH" : Function OFF

"ACT" : Function ON

- When "(4WS>OFF)" is displayed below <CH3>ABS, the CH3 brake cannot be used if the 4WS function is not set to "ACT".

- When "(ESC>INH)" is displayed under <CH4>ABS, the CH4 brake cannot be used if the dual ESC function is not set to "INH".

### 2 (Brake rate)

Using the (JOG) button, select "RATE" of <CH3> for CH3 brake and "RATE" of <CH4> for CH 4 brake , and use the (+) and (-) buttons to adjust the Brake rate amount.

### 3 (Delay amount setup)

Using the (JOG) button, select "DELY" of <CH3> for CH3 brake, "DELY" of <CH4> for CH 4 brake and "DELY" of <CH2> for CH 2 brake. Use the (+) and (-) buttons to adjust the delay amount.

"0" : No delay

"100" : Maximum delay amount

### 4 (3rd & 4th channels brake-A.B.S ON/OFF)

Using the (JOG) button, select "ABS" of <CH3> for CH3 brake and "ABS" of <CH4> for CH 4 brake.

Use the (+) or (-) key and set the function to the "ACT" state.

### 5 When ending, return to the MENU2 screen by pressing the (JOG) button.

## Setting the 4WS mixing/dual ESC function

To use CH3 of the brake mixing function, 4WS mixing (p.72) must be set to "INH".  
To use CH4 of the dual ESC function (p.74) and CPS mixing (p.78) must be set to "INH".

## Dial / Trim Setting

The function select switch dial function can control the 3rd/4th channels. Brake rate (RATE) can be controlled with digital dial or digital trim, using the function select dial function. (See page 65)

#### Function ON/OFF (MODE)

INH, ACT

#### Select button

- Select with the (+) or (-) buttons.

#### Brake rate (RATE)

0 ~ 100

Initial value:100

#### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.

- Return to the initial value by pressing the (+) and (-) buttons simultaneously for about 1 second.

#### Delay amount (DELY)

(CH3) 0 ~ 100

(CH4) 0 ~ 100

(CH2) 0 ~ 100

Initial value:0

#### Function ON/OFF (ABS)

INH, ACT

#### Select button

- Select with the (+) or (-) buttons.

# Programmable Mix "PROG MIX"

(All channels)

This function allows you to apply mixing between the steering, throttle, channel 3 and channel 4.

## Additional Functions

-When the steering or throttle channel is the master channel (channel that applies mixing), trim data can be added. (Trim mode)

- The mixing mode selection. (Master mixing mode)

Relating function

steering :EPA, STR EXP, D/R, SPEED, 4WS

throttle :EPA, THR EXP, ATL, ABS, SPEED, BRAKE MIX, NT-BRK, ESC MIX, TH ACCEL


CH3 :EPA,BRAKE MIX,4WS

CH4 :EPA,BRAKE MIX,ESC MIX

## Movement of the slave channel side

The movement of the master channel side will be added to the movement of the slave channel side.

Display "PROG MIX" screen by the following method:



### Setup items

MODE	: Function ON/OFF	SLV	: Slave channel
LEFT	: Mixing rate (Left side)	MXMD	: Mix mode
RGHT	: Mixing rate (Right side)	TRIM	: Trim mode
MST	: Master channel		

## Program mixing adjustment

(Preparation)

- When "PROG MIX" is turned ON and OFF by switch, set the switch by select switch dial function (p.65).

### 1 (Mixing function ON/OFF)

Select the setting item "MODE" by the (JOG) button up or down operation. Use the (+) or (-) and set the function to the "ON" or "OFF" state.

"INH" : Function OFF

"ON" : Function ON. When the switch is OFF, "OFF" is displayed.

Function SW  
PROGMIX

Function ON/OFF (MODE)

INH,ON(OFF)

Select button

- Select with the (+) or (-) buttons.

## 2 (Master channel)

Select setup item "MST" y the (JOG) button up or down operation, and select the master channel by pressing the (+) or (-) button.

These setup items are different depending on the master channel.  
Upper side : LEFT/FWRD/UP  
Lower side : RGHT/BRAK/DOWN

PROG MIX  
RT  
MODE: INH  
LEFT: +100  
RGHT: +100  
MST : STR  
SLV : CH3  
MXMD: OFF  
TRIM: OFF

Program mixing function

### Channel selection (MST)

STR, THR, CH3, CH4  
Initial value :STR

### Select button

- Select with the (+) or (-) buttons.

## 3 (Slave channel)

Select setup item "SLV" by the (JOG) button up or down operation, and select the slave channel by pressing the (+) or (-) button.

### Channel selection (SLV)

STR, THR, CH3, CH4  
Initial value :CH3

### Select button

- Select with the (+) or (-) buttons.

## 4 (Left, forward or up side mixing amount adjustment)

Select the setting item "LEFT", "FWRD", or "UP" by the (JOG) button up or down operation. Use the (+) or (-) button and adjust the left, forward, or up side mixing amount.

### Mixing amount

-120~0~+120  
Initial value: +100

### Adjust button

- Use the (+) and (-) buttons to make adjustments.  
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

## 5 (Right, brake or down side mixing amount adjustment)

Select the setting item "RGHT", "BRAK", or "DOWN" by the (JOG) button up or down operation. Use the (+) or (-) button and adjust the right, brake, or down side mixing amount.

### Mixing amount

-120~0~+120  
Initial value: +100

## 6 (Mixing mode setup)

Select setup item "MXMD" by the (JOG) button up or down operation, and use the (+) or (-) button to select the mixing mode.

"OFF":Mixing proportional to master channel operation.  
"MIX" :Mixing by master channel another function considered.

### Mixing mode (MXD)

OFF, ON  
Initial value: OFF

### Select button

- Select with the (+) or (-) buttons.

## 7 (Trim mode setup)

Select setup item "TRIM" by the (JOG) button up or down operation, and use the (+) or (-) button to select the mixing mode.

"OFF":Trim is removed.  
"ON" :Trim is added.

### Trim mode (TRIM)

OFF, ON  
Initial value: OFF

### Select button

- Select with the (+) or (-) buttons.

## 8 When ending, return to the MENU2 screen by pressing the (JOG) button.

### Switch / Dial / Trim Setting

Select the program mixing function ON/OFF switch with the function select switch dial function. Mixing rate (RATE) can be controlled with digital dial or digital trim, using the function select switch dial function. (See page 65)



This function can be used with crawlers and other 4WS type vehicles. It is mixing which uses the 1st CH to control the front side steering and the 3rd CH to control the rear side steering.

OFF (front side only), reverse phase, same phase, rear side only and other 4WS type switching is used by selecting SW1 with the function select switch function (p.65). If not selected, <NO SW> is displayed. Therefore, select SW1.

### Setting Special mixings

When the 3rd CH was set to ACT at Brake Mixing (p.68) or when Gyro Mixing (p.76) is used, 4WS mixing cannot be used.

Display "4WS" screen by the following method:



### 4WS mixing adjustment

(Preparation)

Since this function is used by switching the type of 4WS with a switch, the switch used by the function select switch dial function (page 65) is set.

### Setup items


- MODE : 4WS Type
- RATE : 3ch rate (Rear side)
- MXMD : Mix mode

### Function SW

4WS

# 1 (4WS type selection)

Select the setting item "MODE" by the (JOG) button up or down operation. Use the (+) or (-) and set the function to the "ON" or "OFF" state.



- < NO SW >  
If function's ON/OFF switch is not selected, <NO SW> is displayed.
- The function select switch screen (P65) can be displayed from this screen.

- "INH" :Function OFF (front only)
- "2TYP" :Front side only, reverse phase switching
- "3TYP" :Front side only, reverse phase and same phase switching
- "4TYP" :Front side only, reverse phase, same phase, and rear side only switching


### Function ON/OFF (MODE)

OFF, 2TYP, 3TYP, 4TYP

### Select button

- Select with the (+) or (-) buttons.

Switched in the order shown in the figure below by set SW



# 2 (Rear side travel adjustment)

Select setting item "RATE" by the (JOG) button up or down operation. Adjust the rear side travel with the (+) or (-) button.

### Rear rate (RATE)

0 ~ 100  
Initial value:100

### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

# 3 (Mix mode setting)

Select setting item "MXMD" by the (JOG) button up or down operation. Set the mix mode with the (+) or (-) button.

### Mixing mode (MXMD)

- "OFF" :The EXP function of the 1st CH and other settings are not mixed.
- "ON" :The EXP function of the 1st CH and other settings are mixed.

OFF, ON

Initial value: OFF

### Select button

- Select with the (+) or (-) buttons.

# 4

When ending, return to the MENU screen by moving the cursor to the positions other than SW/DIAL and pressing the (JOG) button.


This function is mixing used with crawlers and other 4WD type vehicles and uses the 2nd CH to control the front motor controller and the 4th CH to control the rear motor controller.

Front drive only, rear drive only, or both front and rear drive can be selected using any programmed DT (digital trim) button.

### Setting Special mixings

When the 4th CH was set to ACT at Brake Mixing (p.68) or when CPS Mixing (p.78) is used, Dual ESC mixing cannot be used.

Display "DUAL ESC" function screen by the following method:




#### Setup items

- MODE : Function ON/OFF
- RATE : 4ch rate (Rear side)
- MXMD : Mix mode
- TRIM : Trim mode

### Dual ESC mixing adjustment

(Preparation)

- This function is used to switch between front drive/4WD/rear drive using one of the dial (trim). Set the desired dial (trim) for this function using the SW/DIAL screen (p.65).



#### Function SW

ESC-MD

The function select switch screen (P65) can be displayed from this screen.

### 1 (Dual ESC setting)

Select the setting item "MODE" by the (JOG) button up or down operation. Set the function by pressing the (+) or (-) button.

- "INH" : Function OFF
- "ACT" : Function ON


#### Function ON/OFF (MODE)

INH, ACT

#### Select button

- Select with the (+) or (-) buttons.

The programmed DT button is used to select the drive type as shown in the figure below.



## 2 (Rear side travel adjustment)

Select the setting item "RATE" the (JOG) button up or down operation. Use when applying a rotation difference to the front and rear wheels by adjusting the rear (CH4) motor controller travel with the (+) or (-) button.

## 3 (Mix mode setting)

Select the setting item "MXMD" the (JOG) button up or down operation. Set the mix mode with the (+) or (-) button.

"OFF" : CH2 EXP function and other settings are not mixed.  
 "ON" : CH2 EXP function and other settings are mixed.

## 4 (Trim mode setting)

Select the setting item "TRIM" the (JOG) button up or down operation. Set the trim mode with the (+) or (-) button.

"OFF" : Front side (CH2) trim data is not included.  
 "ON" : Front side (CH2) trim data is included.

**5** When ending, return to the MENU screen by moving the cursor to the positions other than SW/DIAL and pressing the (JOG) button.

### Dial / Trim Setting

The function select dial function can control the 4th channel's ESC (Rear side) rate (RATE) with digital dial or digital trim, using the function select switch dial function. (See page 65)

### Note:

As this function drives 2 separate motor controllers simultaneously, a mutual load is applied. Use this function carefully so that the motor controllers are not damaged. Futaba will not be responsible for motor controller, motor, and other vehicle trouble due to use of this function.

### Rear rate (RATE)

0 ~ 120  
 Initial value:100

### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

### Mixing mode (MXMD)

OFF, ON  
 Initial value: OFF

### Select button

- Select with the (+) or (-) buttons.

### Trim mode (TRIM)

OFF, ON  
 Initial value: OFF

### Select button

- Select with the (+) or (-) buttons.

This function is a remote gain function which adjusts the sensitivity of the Futaba car rate gyro at the T4PLS side, and is mixing that uses the 3rd CH to adjust the gyro sensitivity.

When using the T4PLS by switching the AVCS and normal modes use SW1 with the function select switch function (p.65).

For a description of the car rate gyro mounting method and handling, refer to the rate gyro instruction manual.


### Setting Special mixings

When the 3rd CH was set to ACT at Brake Mixing (p.68) or when 4WS Mixing (p.72) is used, Gyro mixing cannot be used.

### Dial / Trim Setting

The gain amount can be adjusted by using the function switch dial function (p.65).

Display "GYRO MIX" screen by the following method:




### AVCS / NORMAL Modes

The gyro has 2 operating modes: NORMAL mode and AVCS mode. In the AVCS mode, the angle is controlled simultaneously with NORMAL mode rate control (swing speed). The AVCS mode increases straight running stability more than that of the NORMAL mode. Because the feel of operation is different, choose your favorite mode.


#### NORMAL

Countersteers against outside force, but cannot correct the skid direction.



#### AVCS

Corrects the skidding direction and forcefully maintains the heading.



## Gyro mixing adjustment

(Preparation)

- Refer to the gyro instruction manual and connect the gyro to the receiver. When using remote gain, connect gyro sensitivity adjustment to the 3rd CH of the receiver.
- When using gyro mixing by switching between the NORM (normal) and AVCS modes, use the function select switch dial function (p.65) to set the switch to be used.

### Setup items

MODE : Gyro mode  
 NORM : Normal mode gain  
 AVCS : AVCS mode gain

### Function SW

GYRO  
 SW type  
 ALT

## 1 (Gyro mixing setting)

Select the setting item "MODE" by the (JOG) button up or down operation. Set the function by pressing the (+) or (-) button.


"INH" : Function OFF  
 "NORM" :NORMAL mode gain  
 "AVCS" :AVCS mode gain  
 "SEL" :Switching Normal mode and AVCS mode  
 (Displayed <NO SW> when the Gyro Mode SW is not used.)

### Function selection (MODE)


INH, NORM, AVCS, SEL

### Select button


- Select with the (+) or (-) buttons.



"NORM" mode




"AVCS" mode



"SELE" mode

Shows the gyro mode select switch mode.

Displayed when the Gyro Mode SW is not used.



The function select switch screen (P65) can be displayed from this screen.

Function

## 2 (NORMAL side gain adjustment)

Select the setting item "NORM" by the (JOG) button up or down operation. Adjust the NORMAL side gain with the (+) or (-) button.

(AVCS side gain adjustment)

Select the setting item "AVCS" by the (JOG) button up or down operation. Adjust the AVCS side gain with the (+) or (-) button.

### NORMAL / AVCS gain (NORM / AVCS)

0 ~ 120  
 Initial value:30

### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously for about 1 second.

## 3 When ending, return to the MENU screen by moving the cursor to the positions other than SW/DIAL and pressing the (JOG) button.

# CPS Mixing "CPS MIX"

This function controls the Futaba CPS-1 channel power switch.


Normally, when using the CPS-1 unit to light the vehicle dress-up and other illumination (LED) the CPS-1 unit with LED connected is connected to a vacant switch channel and the LEDs are turned on and off by switch while the vehicle is running. However, when the CPS-1 mixing (CPS MIX) function is used, the LED can be turned on and off and flashed in step with steering and throttle operation, as well as being turned on and off by switch. The flashing speed (cycle) can also be set.

For instance, the LED can be flashed as a brake light by throttle brake side operation.

## Setting Special mixings

When the 4th CH was set to ACT at Brake Mixing (p.68) or when Dual ESC Mixing (p.78) is used, CPS mixing cannot be used.

Display "CPS MIX" screen by the following method:



### Setup items

- MODE : Function ON/OFF, control mode
- POSI : ON/OFF position
- TYPE : ON/OFF type
- TCYCL: Flashing speed

Function

## CPS mixing adjustment

(Preparation)

- Connect the CPS-1 to the 4th CH of the receiver.
- When the LEDs are turned on and off by switch, use the function select switch dial function (p.65) to set the switch to be used.

Function SW  
CH4

## 1 (Control system setup)

Operate the (JOG) button up and down and select the setting item "CTRL". Use the (+) or (-) button and select the function.

"INH" : Function OFF  
"CH4 FUNC" : ON/OFF by switch set at the 4th CH  
"STR NT" : ON at steering neutral  
"STR END" : ON at both sides of steering  
"THR NT" : ON at throttle neutral  
"THR FWD" : ON at throttle forward side  
"THR BRK" : ON at throttle back (brake) side  
"TH NT+BK" : ON at throttle neutral and back (brake) sides

### Function selection (MODE)


INH, CH4 FUNC, STR NTR, STR END, THR NT, THR FWD, THR BRK, TH NT+BK

### Select button

- Select with the (+) or (-) buttons.

## 2 (ON/OFF switching position selection)

Select the setting item "POSI" by the (JOG) button up or down operation. Use the (+) or (-) button and select the ON/OFF position. Since the ON/OFF state is displayed at the right side of the setting item "CTRL", setting can be confirmed while operating the function to be controlled (for example, throttle).



Shows the ON/OFF state

ON/OFF Position (POSI)

5 ~ 95  
Initial value: 50

## 3 (ON/OFF type setup)

Select the setting item "TYPE" by the (JOG) button up or down operation. Use the (+) or (-) button and select the type of LED lighting. Normal ON/Off type or flashing can be selected.

"NORMAL" : Normal ON/OFF type  
"FLASH" : Flashing display

### Function selection (TYPE)

NORMAL, FLASH

### Select button

- Select with the (+) or (-) buttons.

### Flashing cycle (CYCL)

1 ~ 100  
Initial value: 50

### Adjust button

- Use the (+) and (-) buttons to make adjustments.  
- Return to the initial value by pressing the (+) and (-) buttons simultaneously for about 1 second.

## 4 (Flashing cycle setting)

When flashing type "FLASH" was selected at the setting item "TYPE" the flashing speed (cycle) can be set.


Select the setting item "CYCL" by the (JOG) button up or down operation. Use the (+) or (-) button and select the flashing speed (cycle).

## 5 When ending, return to the MENU2 screen by pressing the (JOG) button.

This menu has the following 4 functions:

- Servo neutral mode, which sets the throttle neutral ratio to 7:3 or 5:5
- Idle up, which raises the idling speed when starting the engine to improve engine starting performance of a gasoline car (boat)
- Neutral brake, which applies the brakes at the neutral position of the throttle trigger
- Throttle off (engine cut), which stops the engine of a boat, etc. by operating the throttle servo to the low side regardless of the position of the throttle trigger.

Display "TH MODE" screen by the following method:



### Setup items

SXNT : Throttle servo neutral position  
IDLUP : Idle-Up rate

NTBRK : Neutral brake rate  
THOFF : Throttle off (engine cut) position

## Throttle servo neutral position "SXNT"

-This function allows selection of the forward side and brake (reverse) side operation ratio from 7:3 or 5:5 by changing the neutral position of the throttle servo.



### Selecting the throttle servo neutral position

#### 1 (Mode selection)

Select the setting item "SXNT" by (JOG) button. Select "F5/B5" or "F7/B3" by (+) or (-) button.

"F5/B5" =Forward 50% : Back50%  
"F7/B3" =Forward 70% : Back30%

#### Mode selection (SXNT)

F5/B5, F7/B3

#### Select button

- Select with the (+) or (-) buttons.

#### 2

When ending, return to the MENU screen by moving the cursor to the positions other than SW/DIAL and pressing the (JOG) button

# Idle-Up "IDLUP"

This is a function select switch dial function. The idle up switch must be set. (P65)

This function is used to improve engine starting performance by raising the idling speed when starting the engine of a gasoline car (boat). It is also effective when you want to prevent the braking when the power was turned off during running, due to the effect of your gear ratio setting and choice of motor when operating an electric car. However, considering safety, and to prevent the motor from rotating instantly when the power was turned on, the MC950CR, MC851C, MC602C, MC402CR, and other Futaba MC (Motor Controllers) will not enter the operation mode if the neutral position is not confirmed. When using the MC950CR, MC851C, MC602C, MC402CR, or other Futaba MC, confirm that the MC is in the neutral position and the set is in the operation mode before setting the idle up function switch to ON.

## Operation

The throttle neutral position is offset to the forward side or brake side. There is no linkage locking, etc. because there is no change near the maximum operation angle even when the neutral position is offset by this function.

## Operation Display

While this function is ON, the LED blinks.

< NO SW >  
If function's ON/OFF switch is not selected, <NO SW> is displayed.

The function select switch dial screen (p.65) can be displayed from this screen.

```

TH MODE [RT]
5XNT: F5/B5
VTBRK: 0
THOFF: 0
IDLUP: 0
<NO SW>
SW/DIAL
            
```

If the power switch is turned on while the idle-up switch is on, an audible alarm will be heard. Immediately set the Idle-Up switch to OFF.

WARNING

MIX WARN

IDLUP 0F

THOFF 0F

NEUTRAL BRAKE

Warning display

## Idle-Up function adjustment

(Preparation)

- Use the function select switch dial to select the switch. (p.65)

**1** (Idle-Up rate)  
Select the setting item "IDLUP" by the (JOG) button. Use the (+) and (-) buttons to set the Idle-Up rate.

**2** When ending, return to the MENU screen by moving the cursor to the positions other than SW/DIAL and pressing the (JOG) button

- Adjust button**
- Adjust with the (+) and (-) buttons.
  - Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

**Idle-Up rate (IDLUP)**  
D50 ~ D1, 0, U1 ~ U50

Initial value: 0  
"D": Brake side  
"U": Forward side

## Dial / Trim Setting

The function select dial function can control the Idle-up rate with digital dial or digital trim. (See page 65)

# Neutral Brake "NTBRK"

This is a function select switch dial function. The neutral brake function ON/OFF switch must be set. (P65)

The neutral brake, which applies the brakes at the neutral position of the throttle trigger, can be set. However, when using the MC950CR, MC851C, MC602C, MC402CR, or other Futaba MC (Motor Controller), confirm that the MC is in the neutral position and the set is in the operation mode before setting the neutral brake function switch to ON, the same as the idle up function (P81). In addition, when the idle up function or throttle off function (P83) is set, this function has a higher priority than the neutral brake function.

## Reference

The ESC neutral brake function and T4PLS neutral brake function can be used simultaneously. However, when setting is difficult to understand, we recommend that only one neutral brake function be used.

## Dial / Trim Setting

When the neutral brake function is "ON", the neutral brake rate adjustment is automatically assigned to the throttle trim (DT1/2/3/4 or DL1).

## Operation display

An LED blinks while the neutral brake function is active.

< NO SW >  
If function's ON/OFF switch is not selected, <NO SW> is displayed.

The function select switch screen (p.65) can be displayed from this screen.

```

TH MODE
[RT]
SXNT:F5/B5
NTBRK: 0
THOFF: 0
IDLUP: 0
<NO SW>
SW/DIAL
            
```

If the power switch is turned on while the neutral brake switch is on, an audible alarm will be heard. Immediately set the neutral brake switch to OFF.

WARNING

MIX WARN

IDLE UP  
or  
THOFF  
or  
NEUTRAL  
BRAKE

Warning display

## Neutral Brake function adjustment

(Preparation)

- Use the function select switch dial to select the switch. (p.65)

**1** (Neutral brake rate)  
Select the setting item "NTBRK" by the (JOG) button. Use the (+) and (-) buttons to set the neutral brake rate.

**2** When ending, return to the MENU screen by moving the cursor to the positions other than SW/DIAL and pressing the (JOG) button

### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

### Brake rate (NTBRK)

0 ~ B100  
Initial value: 0

## Effect of set value of other functions on neutral brake

Throttle side EPA function, or ATL function setting, also affects neutral brake side operation.

## Throttle Off (engine cut) "THOFF"


This is a function select switch dial function. The throttle off function ON/OFF switch must be set. The engine cut function stops the engine of a boat, etc. by operating the throttle servo to the slow side by switch regardless of the position of the throttle trigger and the setting of other functions (reverse function setting is effective).

### Dial / Trim Setting

The function select dial function can control the throttle-off position can be controlled with digital dial or digital trim. (See page 65)

### Operation display

An LED blinks while the neutral brake function is active.



### Engine Cut function adjustment

(Preparation)

- Use the function select switch dial to select the switch. (p.65)

#### 1 (Preset position setup)

- Select the setting item "THOFF" by the (JOG) button. Use the (+) and (-) buttons to set the preset position of the throttle servo.

#### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

- #### 2
- When ending, return to the MENU screen by moving the cursor to the positions other than SW/DIAL and pressing the (JOG) button

#### Preset position (THOFF)

0 ~ B100  
Initial value: 0

### ⚠ Caution

- ① Always operate carefully before using this function.

While switch with preset function set is in the ON state, the servo (motor controller) is locked in the preset position and does not operate even if the throttle trigger is operated. If the servo was operated at the wrong setting, you may lose control of the car (boat).

# ESC Link Function "MC LINK"

This is a special function which lets you set the contents of the Link software which performs Futaba speed controller (ESC), MC960CR, MC940CR, MC950CR, MC851C, MC602C, MC402CR, etc. variable frequency and other data changes at the T4PLS transmitter. However, some data changes require a PC and Link software. This function is used by connecting ESC directly to the transmitter. The T4PLS power switch is used at the display side. Use the various optional servo extension cords according to the distance between the transmitter and ESC. The last data read from ESC to T4PLS or the last data written from T4PLS to ESC is saved to the T4PLS. Since the data for each model memory can be saved, the data of up to 40 models can be saved.

-When the T4PLS battery voltage drops, the display switches to low battery display. Therefore, use this function when there is ample battery capacity remaining.


-Also connect the battery at the ESC side.

-**Note:** Do not read to the T4PLS an MC940/960CR whose speed was set to over 99990rpm by Link software side Boost Angle rpm setting.


## Connection diagram



(DISP MENU screen)



(MC LINK screen)



MC LINK [RT]	MC LINK [RT]	MC LINK [RT]	MC LINK [RT]
MODE: READ EXEC: +/- (MC402CR)	MODE: READ EXEC: +/- (MC602C)	MODE: READ EXEC: +/- (MC851C)	MODE: READ EXEC: +/- (MC950CR)
MIN: 3.0 CLH: 300 MAX: 2.5 CTH: 300 SRK: 5PH CLT: 0 DBR: 15 BND: 100 LBP: 3.0 RND: 50 NTB: 0 FHB: 28	MIN: 3.0 CLH: OFF MAX: 1.5 CTH: 300 SRK: MIC CLT: 0 DBR: 12 BND: 100 LBP: 3.0 NTB: 0 FHB: 3	MIN: 3.0 CLH: 300 MAX: 2.5 CTH: 300 SRK: MIC CLT: 0 DBR: 12 BND: 100 LBP: 3.0 NTB: 0 FHB: 0	MIN: 5.0 CLH: OFF MAX: 3.0 REU: BRK SRK: 1.5 LR: 0 DBR: 8 BND: 100 LBP: 2.5 RND: 100 NTB: 2 FHB: 6
MC402CR	MC602C	MC851C	MC950CR

MC LINK [RT]	MC LINK [RT]
MODE: READ EXEC: +/- (MC960CR)	MODE: READ EXEC: +/- (MC940CR)
MIN: 5.0 CLH: OFF MAX: 3.0 REU: BRK SRK: 1.5 BND: 100 DBR: 8 BND: 100 LBP: 2.8 Bk5: 0 NTB: 0 BEC: 6.0 TBN: OFF P2 →	MIN: 5.0 CLH: OFF MAX: 3.0 REU: BRK SRK: 1.5 BND: 100 DBR: 8 BND: 100 LBP: 2.8 Bk5: 0 NTB: 0 BEC: 6.0 TBN: OFF P2 →
MC960CR	MC940CR

## Using the ESC Link function

(Preparation)

-Connect the T4PLS and ESC in accordance with the connection diagram, and connect the battery to ESC.

- 1 Set the transmitter power switch to the display side (DISP).  
Display the MC LINK function screen in the above manner.

- 2 (ESC read)

Execute this function to read the connected ESC type and the data currently set at the amp. To save the ESC data to the T4PLS, rewrite the read data.



When you want to write the data saved in the T4PLS to an ESC of the same type, execute the following "WRITE"(write) without executing "READ"(read).

**a** -Select the setting item "MODE" by the (JOG) button, and select "READ" by (+) or (-) button.

**b** -Select the setting item "EXEC:+/-" by the (JOG) button, and press the (+) and (-) buttons simultaneously for 1 second or longer.

- "COMPLETE!" blinks on the screen and the ESC type and currently set contents are read.

- If "LINK ERROR" blinks on the screen, communication with the amp is not being performed normally. Check the T4PLS and ESC connection and the battery connection to ESC and the ESC power switch and repeat steps a→b.



### 3 (Writing to ESC)

Execute this function to write the setting data to ESC. See pages 84~85 for the setting data contents.



**a** -Select the setting item "MODE" by the (JOG) button, and select "WRITE" by (+) or (-) button.

**b** -Select the setting item "EXEC:+/-" by the (JOG) button, and press the (+) and (-) buttons simultaneously for 1 second or longer.

- "COMPLETE!" blinks on the screen and the setting data is written to ESC.

If "LINK ERROR" blinks on the screen, communication with the amp is not being performed normally. Check the T4PLS and ESC connection and the battery connection to ESC and the ESC power switch and repeat steps a→b. In addition, if (NO DATA) is displayed on the T4PLS screen, "WRITE" cannot be selected because there is no setting data to be written.

- Different type ESC data cannot be written. If writing is attempted, "TYPE ERROR" will link on the screen to show that the ESC type is wrong.



### 4 (Initialization)

This function writes the MC setting data set at the factory to the connected MC and T4PLS. Perform "READ" before performing initialization.

**a** -Select the setting item "MODE" by the (JOG) button, and select "RESET" with the (+) or (-) button.

**b** -Select the setting item "EXEC:+/-" by the (JOG) button, and press the (+) and (-) buttons simultaneously for approximately 1 second

- "COMPLETE!" blinks on the screen and the initial data is written to the ESC. If "LINK ERROR" blinks, communication with the amp was not performed normally. Check the T4PLS and ESC connection and the battery connection to ESC and the ESC power switch, and repeat steps a→b. In addition, when (NO DATA) is displayed on the T4PLS screen "RESET" cannot be selected because there is no write initial data.




## ESC function setup (MC601/602/850/851C, 401/402/950CR)

- 1 Select the setting item by the (JOG) button.  
Set the value by (+) and (-) button.

### Setup item selection

- Select by the (JOG) button.



### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

### Setup item

**Min-(PWM FREQ MIN LD) 100Hz~10000Hz (10kHz)**

**MC950CR:500Hz~30000Hz (30kHz)**

Same as Link software PWM frequency (at Min. load),  
Min sets the "0"A PWM frequency at minimum load.

**MAX-(PWM FREQ MAX LD) 100Hz~10000Hz (10kHz)**

**MC950CR:500Hz~30000Hz (30kHz)**

Same as Link software PWM frequency (at Max. load).  
MAX sets the PWM frequency at maximum load at the output current limit value set by Current Limiter.

**BRK-(PWM FREQ BRK LD) nOR(2000Hz)/ HIG(1000Hz)/ SPH(500Hz)**

**MC950CR:500Hz~30000Hz (30kHz)**

Same as Link software Brake PWM at frequency.  
This setting can set the brake PWM frequency.

**nTB-(NEUTRAL BRAKE) 0%(OFF)~100%**


Same as Link software Neutral Brake.

Make this setting when you want to use the brakes at the neutral throttle (OFF) position by throttle operation. The larger this value, the greater the braking force. When you want to use the neutral brake, set this value to "0%".

**CLM-(CURRENT LIMIT) 50A~300A (MC950CR:50A~300A), OFF** Same as Link software Current Limiter.

Current Limiter sets the current value at maximum load here.

Since setting of the MAX is based on the output current limit value set by Current Limiter, Current Limiter does not have to be turned OFF except when a current exceeding 300A is generated.



"Min" which sets the frequency when the load is small, is set to the high frequency side (large value) when extension is desired after straight-aways and curves.

"MAX" which sets the frequency when the load is large, is set to the high frequency side (large value) when you want to suppress the rise from low speed and when motor heating and commutator roughness are sensed.

When the rise from low speed is poor, and becomes bad even when "MAX" is set to the low frequency side, use the log data to check if there was a momentary voltage drop. When you want to suppress the overall power, lengthen the run time, and otherwise improve efficiency, set both "MAX" and "Min" to the high frequency side. When you want to set a fixed PWM frequency at full range regardless of the load current, set PWM frequency (at Max. load) and PWM frequency (at Min. load) to the same value.

**LBP-(LOW BATTERY VOLT) 2.5V~6V****2.5V~7.5V for MC950CR**


Same as Link software Low Bat Protection

This setting cuts off the output to the motor when the running battery voltage drops to the set voltage to prevent the receiver from stopping operation when the supply of voltage to the receiver becomes insufficient while running due to a drop in the power supply voltage. When the power supply voltage recovers, power is supplied to the motor once more.

**DBA-(DEAD BAND) ±2µs~±50µs**

Same as Link software Dead Band.

This sets the range (neutral point range) over which the ESC does not respond to transmitter throttle operation. The larger the set value, the wider this range.



Position at which motor starts to run  
Dead Band  
Point at which brakes start taking effect  
Throttle neutral position

```

MC LINK
[RT]

MOD::WRITE
EXE::+/-
(MC102CR)

MIN: 3.0 | CLH: 300
MAX: 2.5 | CLT: 300
BRK: 5PH | CLT: 0
DBA: 15 | END: 100
LBP: 3.0 | RND: 50
nTB: 0 | FHB: 20
  
```

**CTM-(C.L. TIME LIMIT) 50A~300A /CLT-(C.L. TIMER) 0sec(OFF)~240sec (except MC950CR)**

Same as Link software Current Limiter (Time Limit)/Current Limit timer.

The output current can be limited up to the set time lapse from the start of running. This is effective in preventing the motor from outputting wasted energy when the voltage is high immediately after the power battery was recharged.


- "CTM" (Time Limit) sets the maximum output current within the time the output current is limited.
- "CLT" sets the time the output current is limited. This function is disabled when set to "0" sec.

Since the Current Limit Timer starts when the throttle is operated to the forward side and current is output to the motor, this function begins to operate when the motor is run during trim adjustment, etc.

**FWB-(FORWARD BOOST) 0~100 (except MC850C)**

Same as Link software Forward Boost

Operation near the throttle trigger (stick) neutral position becomes a sharp rise.

**BMD-(BRAKE MAX DUTY) 0%~100%**


Same as Link software Brake Max. Duty.

This setting can set the braking force between the neutral point and Max brake point. The larger this value, the greater the braking force. When set to "0%", the brakes are not effective.

**RMD-(REVERSE MAX DUTY) w/back only 0%~100%**

Same as Link software Reverse Max. Duty

This setting can set the reverse power between the neutral point and Max reverse point. The larger this value, the greater the reverse power. When set to "0%", the reverses are not effective.

**MC950CR only setup item**

```

MIN: 5.0 | CLH: OFF
MAX: 3.0 | REV: BRK
BRK: 1.5 | LA: 0
DBA: 8 | END: 100
LBP: 2.5 | RND: 100
nTB: 2 | FHB: 6
  
```

**REV-(REV CANCEL) BRk /REV**

Same as Link software Reverse Cancel.

When set to BRk, reverse operation is not performed.

**LA-(LEAD ANGLE) 0~1500**

Same as Link software Lead Angle.

The lead angle of the motor can be set at the MC950CR side. However, we recommend that it normally be set to "0". Since this setting is premised on setting by referring to the speed log by the Link software, independent use of the MC LINK function of the T4PLS is recommended.

Function

## ESC function setup (MC940CR, MC960CR)

**1** Select the setting item by the (JOG) button.

Set the value by (+) and (-) button.


Operate the following (JOG) button and switch between Page1 and Page2 of the setup screen.

### Setup item selection

- Select by the (JOG) button.

### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.  
 - Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).



### Setup item

#### Min-(PWM FREQ MIN LD) 1kHz(1000Hz)~30kHz (30000Hz)

Same as Link software PWM frequency (at Min. load),  
 Min sets the "0"A PWM frequency at minimum load.

#### MAX-(PWM FREQ MAX LD) 1kHz(1000Hz)~30kHz (30000Hz)

Same as Link software PWM frequency (at Max. load).  
 MAX sets the PWM frequency at maximum load at the output current limit value set by Current Limiter.

#### BRK-(PWM FREQ BRK LD) 1kHz(1000Hz)~30kHz (30000Hz)


Same as Link software Brake PWM at frequency.  
 This setting can set the brake PWM frequency.

#### nTB-(NEUTRAL BRAKE) 0%(OFF)~100%

Same as Link software Neutral Brake.  
 Make this setting when you want to use the brakes at the neutral throttle (OFF) position by throttle operation. The larger this value, the greater the braking force. When you want to use the neutral brake, set this value to "0%".

#### CLM-(CURRENT LIMIT) 50A~500A

Same as Link software Current Limiter.  
 Current Limiter sets the current value at maximum load here.  
 Since setting of the MAX is based on the output current limit value set by Current Limiter, Current Limiter does not have to be turned OFF except when a current exceeding 300A is generated.



Function

"Min" which sets the frequency when the load is small, is set to the high frequency side (large value) when extension is desired after straight-aways and curves.

"MAX" which sets the frequency when the load is large, is set to the high frequency side (large value) when you want to suppress the rise from low speed and when motor heating and commutator roughness are sensed.

When the rise from low speed is poor, and becomes bad even when "MAX" is set to the low frequency side, use the log data to check if there was a momentary voltage drop. When you want to suppress the overall power, lengthen the run time, and otherwise improve efficiency, set both "MAX" and "Min" to the high frequency side. When you want to set a fixed PWM frequency at full range regardless of the load current, set PWM frequency (at Max. load) and PWM frequency (at Min. load) to the same value.

**LBP-(LOW BATTERY VOLT) 2.5V~7.5V**  
 Same as Link software Low Bat Protection  
 This setting cuts off the output to the motor when the running battery voltage drops to the set voltage to prevent the receiver from stopping operation when the supply of voltage to the receiver becomes insufficient while running due to a drop in the power supply voltage. When the power supply voltage recovers, power is supplied to the motor once more.


```

MC LINK
[RT]
MODE: READ
EXEC: +/-
(MC948CR)

Min: 5.0 CLN: OFF
Max: 3.0 REV: BRk
Brk: 1.5 RND: 100
DBR: 8 RND: 100
LBP: 2.8 BkS: 0
nTB: 0 BEC: 6.0
TBN: OFF
P2 →
  
```

Page1


**DBA-(DEAD BAND) ±2µs~±50µs**  
 Same as Link software Dead Band.  
 This sets the range (neutral point range) over which the ESC does not respond to transmitter throttle operation. The larger the set value, the wider this range.



**REV-(REV CANCEL) BRk /REV**  
 Same as Link software Reverse Cancel.  
 When set to BRk, reverse operation is not performed.

**BMD-(BRAKE MAX DUTY) 0%~100%**  
 Same as Link software Brake Max. Duty.  
 This setting can set the braking force between the neutral point and Max brake point. The larger this value, the greater the braking force. When set to "0%", the brakes are not effective.

**RMD-(REVERSE MAX DUTY) w/back only 0%~100%**  
 Same as Link software Reverse Max. Duty  
 This setting can set the reverse power between the neutral point and Max reverse point. The larger this value, the greater the reverse power. When set to "0%", the reverses are not effective.



```

MC LINK
[RT]
MODE: READ
EXEC: +/-
(MC948CR)

Min: 5.0 CLN: OFF
Max: 3.0 REV: BRk
Brk: 1.5 RND: 100
DBR: 8 RND: 100
LBP: 2.8 BkS: 0
nTB: 0 BEC: 6.0
TBN: OFF
P2 →
  
```

Page1

**BKS-(BRAKE SLOPE) 0~300 (Only when used TBM-LEV2)**  
 Same as Link software Brake Slope.  
 This function adjusts the braking effect when the throttle was returned (throttle off). It cancels operation like that called engine brake of actual vehicles.

**BEC-(BEC VOLT) 6.0V /7.4V**  
 Same as Link software BEC Volt.  
 The receiver BEC voltage can be selected from 60V and 74V. Match the voltage to the rating of the servo connected to the same receiver. This BEC voltage cannot output a voltage higher than the input voltage.

Function

```

MC LINK
[RT]

MODE:READ
EXEC: +/-
(MC948CR)

MIn: 5.0 CLN:OFF
Mx: 3.0 REV:BRk
BRk: 1.5 BMD:100
D&R: 8 RMD:100
L&P: 2.8 Bk5: 0
nTB: 0 B&C:6.0
TBM:OFF
P2 →

```

Page1

### TBM-(TURBO MODE) OFF /LV1 /LV2

Same as Link software Turbo Mode

This function sets the turbo mode. More power can be displayed by using the turbo mode. Depending on the setting, the motor and ESC may be damaged so make this setting carefully.

(Note) When LAU (LEAD ANGLE USE) is off, lead angle setting will not operate even if set to LEV1 or LEV2. (Turbo mode disabled, TBM=OFF)

### OFF mode: (No Lead Angle mode) Lead angle - No

When used in races in which the lead angle setting function is inhibited by ESC, set to this mode. The lead angle function is disabled the same as if LAU (LEAD ANGLE USE) was turned off.

When the lead angle function was disabled by the method described above, the MC960CR shows that the lead angle function is off by blinking a blue LED at an ON 0.1 second, OFF 0.9 second cycle at the neutral point.

### LV1 turbo mode: (Lead Angle mode) Lead angle – Yes

The output can be increased by setting a lead angle.

Depending on the set value, the motor may be damaged so increase the lead angle value in steps from a small value while observing the conditions.

Turn on LAU (Lead Angle Use) and adjust the lead angle by LA-(LEAD ANGLE) and A, B, C, D, E BA-(A, B, C, D, E BOOST ANGLE) value.

### LV2 power mode: (Power Mode) Lead angle – Yes


Displays still more power than a turbo.


However, since even a motor applies a large load on the ESC, make the lead angle larger in steps from a small value while observing the conditions.

Turn on LAU (LEAD ANGLE USE) and adjust the lead angle by LA-(LEAD ANGLE) and A, B, C, D, E BA-(A, B, C, D, E BOOST ANGLE) value.

Function

When "LAU" (LEAD ANGLE USE) is turned on "LA" (LEAD ANGLE) is the lead angle can be set. In addition, the "BOOST ANGLE" and "BOOST ANGLE RPM" can be set.







Page2

- LAU-(LEAD ANGLE USE) ON/OFF**  
 Same as Link software Lead Angle Use  
 This function is effective when TBM (Turbo Mode) is LEV1 or LEV2 and sets whether or not lead angle is used. This setting has priority over the TURBO MODE setting. When using in races in which the lead angle function is inhibited by the ESC set this function to OFF.  
 OFF : Lead angle function not used.  
 ON : Lead angle used
- LA-(LEAD ANGLE) 0~59deg**  
 Same as Link software Lead Angle  
 When LAU (LEAD ANGLE USE) is turned on the motor lead angle can be set at the MC960CR. The lead angle can be set up to 59 degrees in 1 degree increments.
- A,B,C,D,E BA-(A,B,C,D,E BOOST ANGLE) 0~59deg**  
 Same as Link software Boost Angle  
**A,B,C,D,E RPM-(A,B,C,D,E BOOST ANGLE RPM) 0~99990rpm**  
 Same as Link software Boost Angle rpm  
 When LAU (LEAD ANGLE USE) is turned on the lead angle versus motor speed of the 5 points A to E can be set. The lead angle can be set up to 59 degrees in 1 degree increments.  
**Note:** Do not read to the T4PLS an MC940/960CR whose speed was set to over 99990rpm by Link software side Boost Angle rpm setting.

The LA-(LEAD ANGLE) and A, B, C, D, E BA- (A, B, C, D, E BOOST ANGLE) relationship is shown on the graphs below. Graph [A] shows the relationship when the same value is set at points A, B, C, D, E BA- (A, B, C, D, E BOOST ANGLE) of [A] and [B] and the LA-(LEAD ANGLE) was set to "0" and graph [B] shows the relationship when a value other than "0" was set at LA-(LEAD ANGLE).

As shown in the graphs, [B] is added to the A, B, C, D, E BA-(A, B, C, D, E BOOST ANGLE) set lead angle and [A] is added to the LA-(LEAD ANGLE) set lead angle. For example, if "3" is set at ABA and LA of [B] is set to "2", the actual ABA becomes 3+2=5 (deg). Since LA of [A] is "0", the actual ABA also becomes 3+0=3 (deg).



When using in races in which the lead angle setting function is inhibited by the ESC, set LAU (LEAD ANGLE USE) to OFF. The LAU setting has priority over TBM-(TURBO MODE). If LAU is set to "OFF", the lead angle setting function can be turned off even if TBM is set to "LV1" or "LV2".  
 The MC940,960CR shows that the lead angle setting function is OFF ("0" timing) by blinking a LED.

Function


## Data Transfer "MDL TRANS"

This function copies the model memory data of one T4PLS to another T4PLS. Connect the communication port of both T4PLS with the optional DSC cord for T4PK. Use with this function with the T4PLS power switch at the display side.


**Note:** If the T4PLS battery voltage drops, the display switches to low battery display. Therefore, use this function when there is ample battery capacity remaining.

Note: Since the receiving side writes the new contents of the currently selected model memory, always check the model number before executing this function.

Data is not interchangeable with another type of transmitter.



Display "MDL TRANS" screen by with the T4PLS power switch at the display side and following method:



### Using the Data Transfer function

(Preparation)


- Connect the communication port of both transmitters with the optional DSC cord for T4PK.

- 1 Set the power switch of both transmitters to the display (DISP) side.  
Use the (JOG) button and (+) button to display the "MDL-TRN" at both transmitter.

## 2 (Select the setting item )

"MODE" by the (JOG) button up or down operation, and select the transfer side and receive side by (+) or (-) button.

"TRAN":Data transfer side  
"RCV":Data receive side




**Mode selection**  
"TRANSFER" "RECEIVE"  
**Setup item selection**  
- Select by (JOG) button up or down operation.  
**Mode change button**  
- Use the (+) and (-) buttons to make adjustments.

## 3 (Data transfer execution)

Select the setting item "EXEC" by (JOG) button up or down operation of both transmitter.


First, press the receive side "RCV" transmitter (+) and (-) buttons simultaneously. The message "RCV WAIT.." appears and count down begins.



**Transfer execution button**  
- (+) and (-) buttons pressed simultaneously for about 1 second.  
- 30 seconds wait is displayed on the receive side screen.


Within 30 seconds, press the transfer side "TRANS" transmitter (+) and (-) buttons simultaneously. (If data transfer is not executed within 30 seconds, an error will be displayed at the receive side "RCV" transmitter.)

- "COMPLETE!" is displayed on the screen of the receive side "RCV" transmitter and data transfer is ended.




"COMPLETE!" is displayed.

-If "RCV ERROR!" is displayed on the screen of the receive side "RECEIVE" transmitter, data transfer was not performed normally. Check the connection and repeat steps 1→3. Since the transfer side "TRANS" transmitter only sends, "COMPLETE!" is displayed even when data transfer was not performed normally.



"RCV ERROR!" is displayed.

Data transfer can also be canceled before the end of transfer by operating the (JOG) button at a T4PLS that is waiting to receive data.





"CANCEL" is displayed.

When ending, return to the DISP MENU screen by pressing the (JOG) button.

# Timer Function "TIMER"

Use the timer by selecting one of the three timers UP TIMER, DOWN TIMER, and LAP TIMER.

Display "PTIMER" screen by the following method:




## UP TIMER function

### Up timer function

- This function can be used to count the time between start and stop, etc.
- The timer repeatedly starts and stops each time the switch is pressed and accumulates the time between each start and stop. When the count reaches 99 minutes 99 seconds, the count returns to 00 minutes 00 seconds and is repeated.
- The first start operation can be linked to the throttle trigger.
- The passage of time is announced by sounding of a buzzer (beep) each minute after starting.

- Alarm :Beep sounds at the set time (minute).
- Prealarm :Alarm advance announcement sound. Beeping begins 5 seconds before the alarm.(beeps)


- After starting, the timer continues to count and can be stopped by switch even when the LCD switches to another screen.



# FUEL DOWN TIMER function

## Fuel down timer function

- This function is primarily used to check the refueling time of a gasoline car. (The remaining time is displayed.)
- Each time the switch is pressed, the timer is restarted and the set time is reset. The start time becomes the alarm set time. (When counted down to 00 minute 00 second, the down timer becomes an up timer.)
- The down timer can be initially started by throttle trigger.
- The passing of time is indicated by sounding of a buzzer (beep) each minute after starting.



- Alarm :A beep sounds at the set time (minute).
- Prealarm :Alarm advance announcement sound. Beeping begins 5 seconds before the alarm.(beeps)

- After starting, the timer continues to count even if the LCD switches to another screen.


# LAP TIMER

## Lap timer function

- Each lap time can be memorized by switch operation. (100 laps)
- The race time can be set. Switch operation after the time set by alarm has elapsed automatically stops the timer. The passing of time is indicated by sounding of a buzzer (beep) each minute after starting.

- Alarm :Beep sounds at the set time.
- Prealarm :Alarm advance announcement sound. Sounding begins 5 seconds before the alarm. (beeps)


- The lap timer can be initially started by throttle trigger.



## (LAP TIMER operation)

- The lap timer is started by switch or throttle trigger.
  - Number of laps (LAP): After starting, the timer is counted up and the lap time blinks for 3 seconds each time the switch is pressed. To prevent erroneous counting, switch operation is not accepted during this period. When 1 lap exceeds 10 minutes, counting is repeated from 0.
  - Lap list: Up to 10 lap times are memorized beginning from lap list 1. After lap memory "No.100", operation returns to lap memory "No.1" and the lap memories are overwritten.
  - The lap time data memorized in the lap memories can be checked with the lap list screen (p.92). The entire lap list data is cleared the next time the lap timer is started.
  - TIME: For the first 3 seconds, the preceding lap time is displayed. After that the current lap time is displayed.

## Timer screen



### Racing timer type selection

(Preparation)

Assign the "TIMER" switch using the function select switch (p.65).

#### 1 (Racing timer type selection)

Select the setting item "TYPE" by the (JOG) button. Use the (+) or (-) button and set the racing timer type.

Timer selection (TYPE)  
UP : Up timer  
DOWN : Down timer  
LAP : Lap timer

#### Setup item selection

- Select by the (JOG) button.

#### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.

#### 2 When ending, return to the MENU2 screen by pressing the (JOG) button.

## Using the up timer

(Preparation)

Select the setting item "TYPE" by the (JOG) button.


Press the (+) or (-) button and select "UP".

### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Press the (+) and (-) buttons simultaneously (approx. 1 sec) to return to the HOME screen.

### 1 (Alarm time setting)

Select the setting item "ALRM" by the (JOG) button and set the alarm time with the (+) or (-) button.



### Alarm time (ALRM)

OFF, 1 ~ 99 m  
Initial value: 5 m


### 2 (Timer start/stop operation)

Start the timer by pressing the switch ("TIMER") set by function select switch function.

Stop the timer with the same switch ("TIMER") as start.

- Linking only start to the throttle trigger

Select the setting item "RST" by the (JOG) button and press the (+) and (-) buttons simultaneously for approximately 1 second. When the set beeps and the status display switches from "RST" to blinking "RDY", the system enters the trigger operation ready state. When the trigger is operated at the forward side, the timer starts. (Status display "RUN")



### Switches

Time start / stop


### Status display

RST :Reset state  
RDY :Throttle trigger operation wait  
RUN :Timer running  
STP :Timer stopped

If the (JOG) button is pressed while the timer is operating, the LCD returns to MENU2 screen.

### 3 (Timer reset operation)

Select a status display ("RUN", "STP", or "RDY") by the (JOG) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beep is generated and "RST" appears on the status display and the timer resets.



### Status display

RST :Reset state  
RDY :Throttle trigger operation wait  
RUN :Timer running  
STP :Timer stopped

## Using the fuel down timer

(Preparation)

Select the setting item "TYPE" by the (JOG) button.


Press the (+) or (-) button and select "DOWN".

### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Press the (+) and (-) buttons simultaneously (approx. 1 sec) to return to the HOME screen.

### 1 (Alarm time setting)

Select the setting item "ALRM" by the (JOG) button and set the alarm time with the (+) or (-) button.



#### Alarm time (ALRM)

OFF, 1 ~ 99 m  
Initial value: 5 m

### 2 (Alarm start/restart operation)

When the switch ("TIMER") set by function select switch function is pressed, the timer starts. When the same switch ("TIMER") is pressed while the timer is operating, the timer is reset and simultaneously restarted. (Restart)

- Linking only start to the throttle trigger

Select the setting item "RST" by the (JOG) button and press the (+) and (-) buttons simultaneously for about 1 second. When the set beeps and the status display switches from "RST" to blinking "RDY", the system enters the trigger operation ready state.

When the trigger is operated at the forward side, the timer starts. (Status display "RUN")



### Switches

Timer start / restart

#### Status display

RST :Reset state  
RDY :Throttle trigger operation wait  
RUN :Timer running  
STP :Timer stopped

If the (JOG) button is pressed while the timer is operating, the LCD returns to MENU2 screen.

### 3 (Timer reset operation)

Select a status display ("RUN") by the (JOG) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and "RST" appears on the status display and the timer resets.



#### Status display

RST :Reset state  
RDY :Throttle trigger operation wait  
RUN :Timer running  
STP :Timer stopped

## Using the Lap timer


(Preparation)

Select the setting item "TYPE" by the (JOG) button.

Press the (+) or (-) button and select "LAP".

### 1 (Alarm time setting)

Select the setting item "ALRM" by the (JOG) button and set the alarm time with the (+) and (-) buttons.



#### Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Press the (+) and (-) buttons simultaneously (approx. 1 sec) to return to the HOME screen.

#### Alarm time (ALRM)

OFF, 1 ~ 99 m  
Initial value: 5 m

### 2 (Timer start/ lap count/ stop operation)

When the Timer switch (set in the Function select menu) is pressed, the timer starts. During operation, the same switch becomes the lap switch and when the set time elapses, the timer is stopped by the same switch (TIMER)

- Linking only start to the throttle trigger

Select the setting item "RST" by the (JOG) button and press the (+) and (-) buttons simultaneously for about 1 second. When the set beeps and the status display switches from "RST" to blinking "RDY", the system enters the trigger operation ready state. When the trigger is operated at the forward side, the timer starts. (Status display "RUN")



#### Switches

Timer start / Lap count

#### Status display


RST :Reset state  
RDY :Throttle trigger operation wait  
RUN :Timer running  
GOAL: Timer stopped

When the switch (TIMER) is pressed after the time set by alarm has elapsed, the timer stops and the lap time and total time are memorized. The status display becomes "GOAL".

If the (JOG) button is pressed while the timer is operating, the LCD returns to MENU2 screen.

### 3 (Timer reset operation)

Select a status display ("GOAL") by the (JOG) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and "RST" appears on the status display and the timer resets.



#### Status display

RST :Reset state  
RDY :Throttle trigger operation wait  
RUN :Timer running  
GOAL: Timer stopped

- When reset operation was performed before the "ALRM" set time had elapsed, the total time is not memorized.
- The lap memory data can be checked with the lap list (P98) screen.

# Lap List "LAP LIST"



The lap list is displayed when checking the lap memory data (lap times) memorized by lap timer (P99) operation.

- After the lap timer starts, the lap times are memorized sequentially each time the switch is operated.

- If the timer is stopped after the set ALRM time has elapsed, the final lap time is memorized and the total time after the last lap is automatically written.

- When the timer was stopped before the set ALRM time has elapsed, the total time is not memorized.

Display "LAP LIST" screen by the following method:



## Using the lap memory

### 1 (Lap memory check)

When the (JOG) button is pressed, the list is scrolled every 10 laps and each lap time can be checked.

### 2 (Lap memory total data reset)

Press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and all the data is reset.

#### Reset button

- Reset by pressing the (+) and (-) buttons simultaneously for about 1 second.


### 3 When ending, return to the MENU2 screen by pressing the (JOG) button.

# System Functions "SYSTEM"

The graphic liquid crystal screen display mode, buzzer sound and menu character mode, etc can be set.

- "CONTRA"---Liquid crystal screen contrast adjustment (20 steps)
- "BK-LHT"---Liquid crystal screen backlighting display mode setup  
(OFF, ON at button operation, normally ON)
- "LHT-TM"---Setting of ON time (1~30 secs) when [ON at button operation] was selected above.
- "LHT-PW"---Liquid crystal screen backlighting brightness adjustment (30 steps)
- "BATT"---Battery type setting (LiFe2/NiMH5/DRY4)  
The T4PLS can use an optional rechargeable battery. However, the battery alarm setting is different from that of the dry cell battery (alkaline battery recommended). Therefore, always set the battery type to match the power source used.  
If used with the incorrect setting, the normal low battery alarm function will not work and the system may stop before a battery alarm is generated. The usage time may also become extremely short.
- "BUZZER"---Buzzer sound tone adjustment (OFF, 100 steps)
- "OPE-TM"---The power off forgotten alarm setting (OFF, 10 m)
- "MENU"---Item which displays the basic menu screen in katakana characters for Japanese use.
- "DISP"---HOME screen display mode setting (Telemetry data, Timer, Users name)

Display "SYSTEM" screen by the following method:



```

SYSTEM
  RT
CONTRA: 0
BK-LHT: KEY
LHT-TM: 10s
LHT-PW: 15
BATT: DRY4
BUZZER: 65
OPE-TM: 10m
MENU : ENG
DISP: TLMTR
  
```

### Setup items

- CONTRA : Contrast
- BK-LHT : Backlighting mode
- LHT-TM : Backlighting time
- LHT-PW : Backlighting brightness
- BATT : Battery type
- BUZZER : Buzzer tone
- OPE-TM : Power off forgotten alarm
- MENU : Menu screen character
- DISP : HOME screen display mode

Function

1 (Setting of each item)

**(Adjusting the liquid crystal contrast)**

Select the setting item "CONTRA" by the (JOG) button, and use the (+) and (-) buttons to adjust the screen contrast.

- Adjust to an easy-to-see contrast.

When ending, return to the MENU2 screen by pressing the (JOG) button.



**Adjustment buttons**

- Use the (+) and (-) buttons to make adjustments.
- Press the (+) and (-) buttons simultaneously (approx. 1 sec) to return to the initial value.

**Contrast (CONTRA)**  
 -10~0~+10  
 Initial value: 0

**(Setting the liquid crystal backlighting mode)**

Select the setting item "BK-LHT" by the (JOG) button, and select the mode by pressing the (+) or (-) button.

- "KEY" :Fixed time backlighting ON after button operated.
- "ALL" :Backlighting always ON
- "OFF" :Backlighting OFF

When ending, return to the MENU2 screen by pressing the (JOG) button.



**Backlight mode (BK-LHT)**  
 KEY, ALL, OFF

**(Setting liquid crystal backlighting time)**

Select the setting item "LHT-TM" by the (JOG) button, and use the (+) and (-) buttons to set the ON time.

- When "KEY" is set at the preceding item, this ON time becomes effective.

When ending, return to the MENU2 screen by pressing the (JOG) button.



**Backlighting time (LHT-TM)**  
 1~30  
 Initial value: 10

**(Setting liquid crystal backlighting brightness)**

Select the setting item "LHT-PW" by the (JOG) button, and use the (+) and (-) buttons to set the ON time.

-If too bright, the battery will be consumed.

When ending, return to the MENU2 screen by pressing the (JOG) button.



**Backlighting brightness (LHT-PW)**  
 1~30  
 Initial value: 15

### (Setting the battery type)



Select the setting item "BATT" by the (JOG) button, and select the mode by pressing the (+) or (-) button. When changing the battery type, press the (JOG) button after thoroughly checking whether or not the mistake was made again. An electronic beeping sound is generated and the setting is changed.

**Note:** If the battery type is changed to the wrong setting, the low battery alarm will be generated immediately after the change and operation will become impossible.

When the low battery alarm was generated, turn off the power and replace the battery with a fully charged battery or a new dry cell battery and then reset the battery type.

**Note:** If used with the incorrect setting, a normal low battery alarm will not be generated and the system may stop before the battery alarm is generated. The usage time may also become extremely short.

- "LiFe2" :Futaba LiFe type battery (FT2F1700B/2100B)
- "NiMH5" :Futaba NiMH type battery (HT5F1800B)
- "DRY4" :Dry cell battery (alkaline battery recommended) 4 batteries




When ending, return to the menu screen by pressing the (JOG) button.

### (Adjusting the buzzer tone)

Select the setting item "BUZZER" by the (JOG) button, and use the (+) and (-) buttons to adjust the tone.

- Decide by referring to the tone at adjustment.

When ending, return to the menu screen by pressing the (JOG) button.



### (Changing the power off forgotten alarm setting)

Select the setting item "OPE-TM" by the (JOG) button, and use the (+) and (-) buttons to select the power off forgotten alarm mode.

- "10m" :If an operation is not performed within 10 minutes while the power is on, an audible alarm sounds.
- "OFF" :Power off forgotten alarm setting OFF




→ The power off forgotten alarm (OPE-TM)  
10m, OFF

When ending, return to the menu screen by pressing the (JOG) button.

### (Changing the menu character display)

Select the setting item "MENU" by the (JOG) button, and set the basic menu character display with the (+) or (-) button. (See page 37)

- "ENG" : Basic menu displayed in Alphabetic character.
- "カナ" : Basic menu displayed in katakana character.



→ Menu charactre (MENU)  
ENG, カナ


When ending, return to the menu screen by pressing the (JOG) button.

### (Changing the HOME screen display mode)


Select the setting item "DISP" by the (JOG) button, and set the HOME screen display mode with the (+) or (-) button.

- "TLMTR" :Telemetry data is displayed
- "TIMER" :Timer is displayed
- "USER" :User name is displayed


Only the T-FHSS system can display telemetry data. Nothing is displayed with an S-FHSS/FHSS system.




→ HOME screen mode (DISP)  
ENG, カナ



TLMTR



TIMER




USER

# Adjuster "ADJUSTER"

Steering wheel and throttle trigger neutral position and servo operating angle correction can be applied. This is used when a mechanical offset has occurred for some reason.

\*However, when correction is made, the set value of all the setting functions must be rechecked.

Display the adjuster screen from the system menu.



## Steering adjustment

(Preparation)

On the ADJUSTER screen, select the setting item "WHEEL" by the (JOG) button, and pressing the (JOG) button.

### 1 (Steering neutral adjustment)

In the neutral setup screen (fig-1) state, lightly pull the steering wheel and then press the (JOG) button in the state in which the wheel is not being touched.




fig-1

### 2 (Steering throw adjustment)

In the throw setup screen state (fig-2), lightly turn the wheel fully to the left or right and when button mark (fig-3) is displayed, pressing the (JOG) button.




fig-2




fig-3

Internal check is performed automatically. When each adjustment point is within a fixed range, correction is performed and "COMPLETE" (fig-4) is displayed.

If an adjustment point is not within a fixed range, correction is not performed and the correction data is not updated.

When button mark is not displayed even though correction was performed again, please contact a Futaba Radio Control Customer Center.




fig-4

### 3 When ending, return to the MENU2 screen by pressing the (JOG) button.

Function

## Throttle adjustment

(Preparation)

On the ADJUSTER screen, select the setting item "THROTTLE" by the (JOG) button, and pressing the (JOG) button.

### 1 (Throttle neutral adjustment)

In the neutral setup screen (fig-1) state, lightly pull the throttle trigger and then press the (JOG) button in the state in which the trigger is not being touched.




fig-1

### 2 (Throttle throw adjustment)

In the throw setup screen state (fig-2), lightly operate the trigger fully to the brake side and the forward side and when button mark (fig-3) is displayed, pressing the (JOG) button.

Internal check is performed automatically. When each adjustment point is within a fixed range, correction is performed and "COMPLETE!" (fig-4) is displayed.

If an adjustment point is not within a fixed range, correction is not performed and the correction data is not updated.

When button mark is not displayed even though correction was performed again, please contact a Futaba Radio Control Customer Center.



fig-2




fig-3




fig-4

### 3 When ending, return to the MENU2 screen by pressing the (JOG) button.




# Telemetry/Log Screen Map



Function


# Telemetry Function ON/OFF

The telemetry data can be viewed at the HOME screen and telemetry ON/OFF screen. The telemetry function can also be turned on and off at the telemetry ON/OFF screen. The telemetry ON/OFF and communication status can be checked at the HOME screen.



- Telemetry function :ON
- Receiver ID setting complete.
- Data receiving sensitivity display.
- **TH:OFF** shows that data cannot be received because it is outside the data receiving range or because of the effects of an obstruction or the receiver power is OFF after receiver ID check.
- Telemetry function :ON
- Receiver ID before setting or ID mismatch.
- When the receiver ID is set, before ID check in the receiver power OFF stat.
- Telemetry function :OFF

Refer to the map on page 108 for the telemetry ON/OFF (telemetry) screen display.




## Telemetry function ON/OFF

(Preparation)

- On the HOME screen, open the TELEMETRY ON/OFF screen by pressing the (+) button.

**1** Select the setting item "MODE" by the (JOG) button up or down operation. Set the function by pressing the (+) or (-) button.

"OFF" : Function OFF  
"ON" : Function ON




**2** When ending, move the cursor to [RT] by the (JOG) button, and return to the HOME screen by pressing the (JOG) button.

# Telemetry Sensor Setting

An audible alarm can be generated by the T4PLS from the data from a telemetry sensor. This setting sets alarm ON/OFF and the alarm conditions.

Refer to the map on page 108 for the sensor setting (SENS MODE) screen display.

There are receiver power source (battery) voltage and external power source (drive battery) voltage settings on page 1 of the sensor setting screen and temperature and speed settings on page 2. Pages 1 and 2 are switched by (JOG) button left or right operation.



## Setting method


(Setting of each item)

### Setting the receiver power supply voltage alarm

Display page 1 by (JOG) button left or right operation.

Select "ALRM" of the "\*RX VOLT" setting items by (JOG) button up or down operation, and set alarm ON/OFF with the (+) button or (-) button.

- "OFF" : Alarm OFF
- "ON" : Alarm ON by a voltage drop below the specified voltage



- Alarm ON/OFF**  
ON, OFF  
- Select with the (+) or (-) buttons.
- Voltage alarm**  
3.8V~8.0V  
Initial value: 5V
- Adjust button**  
- Adjust with the (+) and (-) buttons.  
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Select "VOLT" of the "\*RX VOLT" setting items by (JOG) button up or down operation, and set the voltage at which the alarm begins to sound with the (+) button or (-) button. The number of digits can be shifted by (JOG) button left or right operation.

When ending, move the cursor to [RT] by the (JOG) button, and return to the HOME screen by pressing the (JOG) button twice.

### Setting external power supply voltage alarm

Display page 1 by (JOG) button left or right operation.


Select "ALRM" of the "EXT VOLT" setting items by (JOG) button up or down operation, and set alarm ON/OFF with the (+) button or (-) button.

"OFF" : Alarm OFF

"ON" : Alarm ON by a voltage drop below the specified voltage

Select "VOLT" of the "\*EXT VOLT" setting items by (JOG) button up or down operation, and set the voltage at which the alarm begins to sound with the (+) button or (-) button. The number of digits can be shifted by (JOG) button left or right operation.

When ending, move the cursor to [RT] by the (JOG) button, and return to the HOME screen by pressing the (JOG) button twice.



#### Alarm ON/OFF

ON, OFF

- Select with the (+) or (-) buttons.

#### Voltage alarm

0.0V~90.0V

Initial value: 5V

#### Adjust button

- Adjust with the (+) and (-) buttons.

- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

### Setting the temperature alarm

Display page 2 by (JOG) button left or right operation.

Select "UNIT" of the "\*TEMP" setting items by (JOG) button up or down operation, and select Celsius or Fahrenheit temperature display with the (+) button or (-) button.

"°C" : Celsius display

"°F" : Fahrenheit

Select "ALRM" of the "\*TEMP" setting items by (JOG) button up or down operation, and set alarm ON/OFF with the (+) button or (-) button.

"OFF" : Alarm OFF


"ON" : Alarm ON at the specified temperature

Select "TEMP" of the "\*TEMP" setting items by (JOG) button up or down operation, and set the temperature at which the alarm begins to sound with the (+) button or (-) button. Select "TYPE" of the "\*TEMP" setting items by (JOG) button up or down operation, and set the type of sensor with the (+) button or (-) button

"SBS-01T" : Option sensor

"Temp 125" : Option sensor for Europ

When ending, move the cursor to [RT] by the (JOG) button, and return to the HOME screen by pressing the (JOG) button twice.



#### Display type

°C, °F

- Select with the (+) or (-) buttons.

#### Alarm ON/OFF

ON, OFF

- Select with the (+) or (-) buttons.

#### Temperature alarm

-20~200°C/ -4~392°F

Initial value: 200°C/ 212°F

#### Adjust button

- Adjust with the (+) and (-) buttons.

- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

#### Sensor type


SBS-01T, Temp 125

#### Select button

- Select with the (+) or (-) buttons.

### Setting the gear ratio

Display page 2 by (JOG) button left or right operation. Select "RATIO" of the "R.P.M" setting items by (JOG) button up or down operation, and set the location the sensor is to actually measure and the gear ratio of the motor and engine with the (+) button or (-) button. There is no alarm function.



#### Gear ratio (moderating ratio)

0.001~64  
Initial value: 1

#### Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

When ending, move the cursor to [RT] by the (JOG) button, and return to the HOME screen by pressing the (JOG) button twice.

## Log Setting Start/Stop

The data from a telemetry sensor can be saved to the T4PLS as a data log. Since the data is sequentially updated, when data logging is performed, the old data is erased. Only 1 data is saved.

The interval at which the data is acquired can be selected from a minimum 0.1 second to a maximum 60 seconds. Because the maximum count is 200, if the count is made 200 counts at 0.1 second intervals, 20 seconds worth of data is acquired, and if the count is made 200 counts at 60 second intervals, 3 hours 20 minutes worth of data is acquired.

Data logging is started and stopped by setting SW1 set by SW/Dial function (p.65) to "LOGGER" and by switch (SW1). If the switch (SW1) is not set, data logging is started by throttle trigger from the log setting screen.

Data logging can also be started by throttle trigger from this screen and stopped by switch (SW1) set by SW/dial function (p.65).

Refer to the map on page 108 for the log setting (LOG MODE) screen display.

### Log setting method

(Preparation)


When using a switch (SW1) to start and stop data logging, set SW1 to "LOGGER" by SW/dial function (p.65)

- On the HOME screen, open the LOG MODE screen by pressing the (-) button.

#### 1 (Log function ON/OFF)

Move the cursor to the "MODE" setting item by (JOG) button up or down operation, and turn on the log function by setting "MODE" to "ACT" by pressing the (+) button or (-) button.

If "MODE" is not set to "ACT", the log function will not be performed even is the switch, etc. is operated.



#### Function ON/OFF (MODE)

- INH, ACT
- Select with the (+) or (-) buttons.

"INH" : Function OFF  
"ACT" : Function ON

## 2 (Recording cycle setting)

Select the "CYCL" setting item by (JOG) button up or down operation, and set the data acquisition interval from a minimum 0.1 second to a maximum 60 seconds with the (+) button or (-) button.

The maximum recordable time set by CYCL is displayed at END TIME shown below.

```
LOG MODE
  RT
STATE: ---
MODE: INH
CYCL: 1.0s
*END TIME
  0h03m20s
ALRM: OFF
```

### Log recording cycle

0.1~60s(sec)  
0.1~10s(sec)0.1s step  
10s~60s(sec)1s step  
Initial value: 1.0sec

### Adjust button

- Adjust with the (+) and (-) buttons.  
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

## 3 (Count alarm ON/OFF)

Select the "ALRM" setting item by (JOG) button up or down operation. To sound an electronic beep at each log count, set "ALRM" to ON with the (+) button or (-) button.

"OFF" : Alarm OFF

"ON" : Alarm ON at each log count

```
LOG MODE
  RT
STATE: ---
MODE: INH
CYCL: 1.0s
*END TIME
  0h03m20s
ALRM: OFF
```

### Log recording time

20s (seconds)~3h 20m (3 hours 20 minutes)  
The maximum recordable time set by CYCL is displayed automatically.

### Alarm ON/OFF

ON, OFF  
- Select with the (+) or (-) buttons.

When ending, move the cursor to [RT] by the (JOG) button, and return to the HOME screen by pressing the (JOG) button twice.

## Log function start/stop operation

### 1 (Log start operation)

#### -Start by switch (SW1)

When the switch (SW1) set by SW/dial function (p.65) is pressed, data logging starts.

#### -Starting by throttle trigger

Display the log setting (LOG MODE) screen and select the "STATE" setting item by (JOG) button up or down operation, and press the (JOG) button for approximately 1 second.

```
LOG MODE
 [ RT ]
STATE: STP
 ( ⚡ →RDY )
MODE: ACT
CYCL: 1.0s
*END TIME
  0h03m20s
ALRM: OFF
```

### Status display

RDY :Throttle trigger operation wait  
STA :Logger running  
STP :Logger stopped

An electronic beeping sound is generated and the "STATE" display switches from "RST" to blinking "RDY", and the logger enters the trigger operation wait state. When the trigger is operated in the forward direction, data logging begins. (STATE display "STA") When the end time arrives, an electronic beep sounds and data logging stops. To return to the HOME screen during data logging, move the cursor to [RT] by (JOG) button up or down operation, and press the (JOG) button or (+) button.

### 2 (Log forced end)

To abort logging, press the switch (SW1), the same as starting, or display the log setting (LOG MODE) screen and select the "STATE" setting item by (JOG) button up or down operation and press the (JOG) button for approximately 1 second. An electronic beeping sound is generated and logging is stopped.


# Log Data List

The log data list can be called when checking the log data memorized by logging operation (P112).


The maximum log data is up to 200 counts.

Refer to the map on page 108 for the log list screen.

## Example: Receiver power supply voltage log list screen.



Refer to the below map for the display method of each log list screen.



Function

### Log list check method

- 1 (Log memory check)  
Each time the (JOG) button is operated up or down the list is scrolled 10 counts and each log data can be checked up to 200 counts.
- 2 When ending, return to the HOME screen by pressing the (JOG) button.

## Ratings

\*Specifications and ratings are subject to change without prior notice.

**Communication method:** One-way operation system  
**Maximum operating range:** 100m (Optimum condition)  
**For safety:** F/S, B-F/S, ID

### Transmitter T4PLS-2.4G

(T-FHSS/S-FHSS/FHSS system, wheel type, 4 channels)

**Transmitting frequency:**

2.4GHz band

**Power requirement:**

(Dry cell battery) Penlight x 4(6V)

**Current drain:**

150mA or less

**Transmission antenna:**

1/2λ di-pole

### Receiver R304SB: (T-FHSS system, 4 channels)

**Power requirement:**

4.8V~7.4V battery / 3.5 ~ 8.4V useable

(Dry cell battery cannot be used.)

**Receiving frequency:**

2.4GHz band

**System:**

T-FHSS system (auto detection)

**Size:**

1.38x0.91x0.33" (35.1x23.2x8.5mm)(excluding a projection part)

**Weight:** 0.23oz. (6.6g)

## Caution

**!** When using the T4PLS in the T-FHSS (HIGH) and S-FHSS (HIGH) mode, always use it under the following conditions:

- Servos** :Futaba digital servo (including BLS Series brushless servos)
- Receiver's battery** :Matched to the ratings of the receiver and connected digital servo (dry cell battery cannot be used).
- Transmitter mode** :RX MODE (See p.29 for setting method.)

Under other conditions, the set will not operate, or the specified performance will not be displayed even if it operates. In addition, it may cause servo trouble. Futaba will not be responsible for damage, etc. caused by combination with the products of other companies.

In addition, the FSU Fail Safe Unit cannot be used because the system is different. Use the fail safe function of the transmitter.


- !** When using analog servos, always switch the T4PLS servo response to the "NORM" mode.  
**Transmitter mode:**"T-FHSS(NORM)", "T-FHSS(NORM)"and FHSS mode (See p.29 for setting method.)  
**Receiver's battery** :Matched to the ratings of the receiver and connected servo (dry cell battery cannot be used).

The set cannot operate in the "HIGH" mode. Operation in this mode will cause trouble with the servo and other equipment. Digital servos (including BLS Series brushless servos) can also be used in the "NORM" mode.

# Warning Displays

## Backup Error

### LCD screen:



If the data is lost for an unknown reason, an audible alarm will sound and "MEMORY BACK UP ERROR" will be displayed on the LCD screen.

### Audible alarm:

**Tone will sound (9 times), then repeat.**


## ⚠ Warning

❗ When a backup error is generated, immediately stop using the system and request repair from the Futaba Service Center.

If you continue to use the system, the transmitter may malfunction and cause loss of control

## Low Battery Alarm

### LCD screen:



If the transmitter battery voltage drops to 4.1V(when using Futaba rechargeable type battery: 4.9V) or less, an audible alarm will sound and "BATTERY LOW VOLTAGE" will be displayed on the LCD screen.

### Audible alarm:

**Continuous tone.**

## ⚠ Warning

❗ When a low battery alarm is generated, cease operation immediately and retrieve the model.


If the battery goes dead while in operation, you will lose control.

## Power supply and low battery alarm

The T4PLS can use an optional rechargeable battery. However, the battery alarm setting is different from that of the dry cell battery (alkaline battery recommended). Therefore, always set the battery type to match the power source used. Always set the battery type to "N5/L2" especially when using a Futaba rechargeable type battery. If the set is used at "DRY4" setting, the time from low battery alarm to system stopping will become extremely short. (See page 101, for a detailed description of the battery types.)

## Memory Error

### LCD screen:




If the data in the transmitter is not transferred normally when the power is turned on, an audible alarm will sound and "MAIN MEMORY ACCESS ERROR" will be displayed on the LCD.

- To stop the alarm, turn off the power.
- Turn the power back on. If the alarm is not generated again, there is no problem.

**Audible alarm:**  
**Tone sounds (7 times) and stops (repeated)**

## MIX Warning

### LCD screen:




When the power switch is turned on while the idle-up, preset (engine cut) or neutral brake function switch is on, an audible alarm will sound and "MIX WARN" will be displayed on the LCD. When that function switch is turned off, the alarm will stop.

**Audible alarm:**  
**Tone sounds (7 times) and stops (repeated)**

## MIX Warning

### LCD screen:




If the power switch is quickly switched from the DISP mode to the PW ON mode or vice versa, the switch error shown at the left may be generated. If this occurs, cycle the power.

**Audible alarm:**  
**Tone sounds (7 times) and stops (repeated)**

## Power off forgotten warning

### LCD screen:



If the T4PL is not operated for 10 minutes, an audible alarm is sounded and "OPE WARN" is displayed on the screen. The audible alarm stops when the steering wheel, throttle trigger, and any dial, switch, or edit button is operated. If you are not going to use the transmitter, turn the power off. (Setting can be reset at the system menu on page 93.)

**Audible alarm:**  
**Tone sounds (7 times) and stops (repeated)**

## Optional Parts

The following parts are available as 4PLS options. Purchase them to match your application. For other optional parts, refer to our catalog.

### Transmitter Battery

---

When purchasing a transmitter battery use the following:

#### Part name

HT5F1800B (6V/1800mAh) Ni-MH battery

FT2F1700(6.4V/1700mAh)/2100B (6.4V/2100mAh) Li-Fe battery

Please do not use the transmitter batteries HT5F1800B and FT2F1700/2100B as the receiver's battery.

Since the transmitter's battery has an overload protection circuit, the output power will be shut down when the high current load is applied. This may result in runaway or fatal crash.

Temperature Sensor (SBS-01T)

RPM Sensor (SBS-01RM)

Voltage Sensor (SBS-01V)

## When requesting repair

Before requesting repair, read this instruction again and recheck your system. Should the problems continue, request as follows.

### (Information needed for repair)

Describe the problem in as much detail as possible and send the letter along with the system in question.

- Symptom (Including the conditions and when the problem occurred)
- R/C System (Send transmitter, receiver and servos)
- Model (Type of model, brand name and model number or kit name)
- Detailed packing list (Make a list of all items sent in for repair)
- Your name, address and telephone number.

### (Warranty)

Read the Warranty card.

- When requesting warranty service, send the card or some type of dated proof purchase.

## **Federal Communications Commission Interference Statement (for U.S.A.)**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **Compliance Information Statement (for U.S.A.)**

This device, trade name Futaba Corporation, model number R304SB, complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
- (3) This module meets the requirements for a mobile device that may be used at separation distances of more than 20cm from human body. To meet the RF exposure requirements of the FCC this device shall not be co-located with another transmitting device.

The responsible party for the compliance of this device is:

FUTABA Corporation of America

2681 Wall Triana Hwy Huntsville, AL 35824, U.S.A.

Phone:1-256-461-9399 FAX:1-256-461-1059

service@futabaUSA.com

## **CAUTION:**

To assure continued FCC compliance:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

## **Exposure to Radio Frequency Radiation**

To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons. This device must not be located or operating in conjunction with any other antenna or transmitter.

---

©Copyright 2018. No part of this manual may be reproduced in any form without prior permission. The contents of this manual are subject to change without prior notice. While this manual has been carefully written, there may be inadvertent errors or omissions. Please contact our service center if you feel that any corrections or clarifications should be made.

FUTABA CORPORATION  
oak kandakajicho 8F 3-4 Kandakajicho, Chiyoda-ku, Tokyo 101-0045, Japan  
TEL: +81-3-4316-4820, FAX: +81-3-4316-4823